

D-A9 // M9 // A7 // A80 // F7 // J7 uto switches are shipped together, but not assembled. (For band mounting, only the auto switch mounting brackets are assembled before shipment.)

When mounting a band on bore size ø8, ø10, or ø12, the D-A9□(V) cannot be mounted.

When mounting a rail on bore size Ø8, Ø10, or Ø12, the D-A9 (V) and A79W cannot be mounted.

When mounting a rail on bore size ø20 or ø25, the D-M9□(V), M9□W(V), and M9□A(V) cannot be mounted.

6

C85 Series



Specifications

Bore	e size [mm]	8	10	12	16	20	25						
Туре				Pneu	matic								
Action			D	ouble actin	g, Single ro	d							
Fluid		Air											
Proof pres	sure	1.5 MPa											
Max. opera	ating pressure	1.0 MPa											
Min. operating	Rubber bumper	0.1 MPa	0.08	MPa		0.05 MPa							
pressure	Air cushion	—	0.08	MPa		0.05 MPa	5 MPa						
Ambient a	nd fluid	Without auto switch: -20°C to 80°C (No freezing)											
temperatu	re	With auto switch: -10°C to 60°C (No freezing)											
Lubricant			١	lot required	d (Non-lube)							
Stroke len	gth tolerance		+1.0	mm		+1.4	mm						
Piston spe	ed	50 to 1500 mm/s											
Cushian		Rubber bumper											
Cushion		— Air cushion											
Allowable	Rubber bumper	0.02 J	0.03 J	0.04 J	0.09 J	0.27 J	0.4 J						
kinetic energy	Air cushion	_	0.17 J	0.19 J	0.4 J	0.66 J	0.97 J						

Symbol



Refer to pages 105 to 115 for cylinders with auto switches.

- Auto Switch Proper Mounting Position
 (Detection at stroke end) and Mounting Height
- Minimum Stroke for Auto Switch Mounting
- Operating Range
- Auto Switch Mounting Brackets/Part No.



Made to Order

-	(For	details,	refer	to	pages	1191	to 1	24.)
_								

Symbol	Specifications
-XA	Change of rod end shape*1
-XB6	Heat-resistant cylinder (-10 to 150°C)*2, *3
-XB7	Cold-resistant cylinder (-40 to 70°C)*3, *4
-XB9	Low speed cylinder (10 to 50 mm/s)*4
-XC4	With heavy duty scraper*4
-XC6□	Made of stainless steel

*1 Excludes the ø8 air cushion

*2 Rubber bumper ø10 to ø25 only

*3 Excludes with rod end (Accessory)

*4 Rubber bumper ø20 and ø25 only

Standard Strokes

Bore size [mm]	Standard stroke [mm]*2*4	Max. stroke ^{*3} [mm]
8 *1	10 25 40 50 80 100	200
10	10, 25, 40, 50, 60, 100	
12	10 25 40 50 80 100 125 160 200	400
16	10, 25, 40, 50, 80, 100, 125, 180, 200	
20	10 25 40 50 80 100 125 160 200 250 200	1000
25	10, 25, 40, 50, 80, 100, 125, 180, 200, 250, 500	1000

*1 Not available with air cushion.

*2 Other strokes are available on request.

*3 For exceeding the standard stroke range, it will be available as a special order (-X2018).

*4 The minimum stroke with air cushion is 25 mm.

Option: Ordering Example of Cylinder Assembly

Cylinder model: CD85N20-50CNW-B-M9BW



Head cover N: Basic (Integrated clevis) Mounting bracket N: Clevis Rod end bracket W: Double knuckle joint Auto switch D-M9BW: Band mounting, 2 pcs.

Mounting bracket, double knuckle joint, and auto switch are shipped together with the product.

▲ Precautions

Be sure to read this before handling the products. Refer to page 219 for safety instructions. For actuator and auto switch precautions, refer to the "Handling Precautions for SMC Products" and the "Operation Manual" on the SMC website: http://www.smcworld.com

ISO Standards Air Cylinder: Standard Double Acting, Single Rod C85 Series

Mounting Brackets/Accessories

			Standard (mour	ted to the body)		Mounting bracket (shipped together)											
M	loun Ae	ting bracket/ ccessory	Mounting nut	Rod end nut	Mounting nut	Foot	Flange	Trunnion	Clevis pivot bracket	Clevis pin	Pin retaining ring	Rod end	Double knuckle joint				
	L	Single foot	• (1 pc.)	• (1 pc.)	_	• (1 pc.)		—	—	—	—	_	_				
Mounting	Μ	Double foot	• (1 pc.)	• (1 pc.)	• (1 pc.)	• (2 pcs.)	_	—	—	—	—	—	—				
bracket	G	Flange	• (1 pc.)	• (1 pc.)	_	_	• (1 pc.)	—	—	—	—	—	_				
symbol	U	Trunnion	• (1 pc.)	• (1 pc.)	—	_	_	• (1 pc.)	—	—	—	—	—				
	Ν	Clevis	• (1 pc.)	• (1 pc.)	_	—		_	• (1 pc.)	• (1 pc.)	• (2 pcs.)	—	_				
Accessory	۷	Rod end	• (1 pc.)	• (1 pc.)	—	—		—	_	_	_	• (1 pc.)	—				
symbol	W	Double knuckle joint	• (1 pc.)	• (1 pc.)	—	—	—	—	_	—	—	_	• (1 pc.)				

Mounting Bracket/Accessory Part Nos.

Moun	ting brookst/Assessory			Bore siz	ze [mm]			Contonto
woun	ung brackel/Accessory	8	10	12	16	20	25	Contents
	Rod end nut	C851	VT10	C851	NT16	C85NT20	C85NT25	1 rod end nut
	Mounting nut	C855	SN10	C855	SN16	C855	SN25	1 mounting nut
	Foot (1 pc.)	C85I	_10A	C85L	_16A	C85	_25A	1 foot bracket
Mounting - bracket	Foot (2 pcs. with 1 mounting nut)	C85I	L10B	C851	_16B	C85I	_25B	2 foot brackets, 1 mounting nut
	Foot (1 pc. with 1 mounting nut)	C85I	_10C	C85L	.16C	C85I	_25C	1 foot bracket, 1 mounting nut
	Flange	C85	F10	C85	F16	C85	F25	1 flange
	Trunnion	C85	T10	C85	T16	C85	T25	1 trunnion
	Clevis	C85	C10	C85	C16	C85	C25	1 clevis pivot bracket, 1 clevis pin, 2 pin retaining rings
	Rod end	KJ	4D	KJ	6D	KJ8D	KJ10D	1 rod end
Accessory	Double knuckle joint	GKM4-8		GKM	6-12	GKM8-16	GKM10-20	1 double knuckle joint
	Floating joint	JA10-	4-070	JA15-	6-100	JA20-8-125	JA30-10-125	1 floating joint

* Refer to page 16 for dimensions of accessories.

Replacement Parts: For Standard Type

Bore size [mm]	Part no.	Note
20	C85A-20PS	Every set includes: 1 rod seal
25	C85A-25PS	1 flat washer 1 retaining ring

When replacing the seals, use grease (GR-S-010: ordered separately) on the sliding parts.

Calculation example: C85N20-50NV • Basic weight 179 g (ø20)

• Accessory: Rod end45 g 179 + 8.1 x 50/10 + 85 + 45 ≈ **350 g**

Weights

[g]													
	Bore size [mm]		8	10	12	16	20	25					
		C85N	37	38 (44)	77 (84)	89 (95)	179 (176)	244 (241)					
	Without magnet	C85E	39	40	81	93	185	249					
	-	C85F	35	37	71	79	164	227					
Basic		C85Y	35	37	72	79	165	228					
weight		CD85N	37	39 (44)	78 (84)	90 (96)	183 (179)	248 (245)					
	With magnet	CD85E	39	41	81	93	188	253					
	-	CD85F	35	37	72	80	168	231					
		CD85Y	36	37	72	80	168	232					
Addition	al weight per 10 mm of st	roke	2.1	2.3	4.1	5.1	8.1	11.3					
	Foot (1 pc.)	C85L□A	2	0		40		95					
Mounting	Foot (2 pcs. with 1 mounting nut)	C85L□B	5	5	1	05	2	10					
bracket	Flange	C85F□	1	2		25		90					
	Trunnion	C85T□	2	0		50		75					
	Clevis	C85C□	2	0		40		85					
	Rod end	KJ□D	1	7		25	45	70					
Accessory	Double knuckle joint	GKM□-□	1	0		20	50	100					
	Floating joint	JAD-D-D	1	0		20	50	70					

(): For air cushion

C85

Stroke Selection

Relationship between cylinder size and maximum stroke

The below table shows the applicable maximum stroke (in cm units), found by calculation assuming the case where the force generated by the cylinder itself acts as buckling force on the piston rod, or piston rod and cylinder tube. Therefore, it is possible to find the applicable maximum stroke for each cylinder size using the relationship between the size of the operating pressure and the cylinder support type, regardless of the load ratio.

[Reference] If it is stopped with the external stopper on the cylinder extension side, even with a light load, the maximum generated force of the cylinder will act on the cylinder itself.

[cm] Applicable maximum stroke [MPa] Mounting according to buckling strength Dressure Support bracket C85 nominal symbol and Dperating minal schematic diagram 25 8 10 12 16 20 Rod Head Foot: M 0.3 24 18 36 26 38 48 Μ flange: G flange: G G 0.5 18 14 27 19 29 36 W Y /Roc side 0.7 14 11 22 16 23 30 豹 0.3 9 6 15 10 15 20 G Head side 6 4 6 0.5 10 10 14 0.7 4 3 8 4 8 11 Rod Clevis: N 0.3 22 17 35 24 36 46 trunnion: U Ν 0.5 16 12 26 18 27 34 0.7 13 10 21 14 22 28 (40)* (40)*1 (40)* 0.3 40)* 80 100)*1 U /Roc 0.5 38 30 (40)* (40)* 61 77 Head side trunnion: U 0.7 32 25 (40)*1 35 51 64 0.3 22 17 35 24 37 47 U 0.5 16 12 26 18 27 35 Head side 0.7 13 10 21 14 22 28 Rod Head (40)*¹ (40)*1 (40)*1 (40)*1 (100)*¹ 100)*1 Foot: M 0.3 flange: G flange: G M G 0.5 (40)* (40)* (40)* (40)* 89 100)* W Rod \$ side 0.7 (40)*1 36 $(40)*^{1}$ (40)*74 93 Ч (40)*1 69 0.3 33 26 37 54 G 0.5 25 19 39 27 41 Head 52 side 0.7 20 15 32 22 33 43 Rod Head Foot: M 0.3 (40)*¹ (40)*1 (40)*1 (40)*1 (100)*1 (100)*1 flange: G flange: G M G 0.5 (40)*1 (40)*1 (40)*1 (40)*1 (100)*1 (100)*1 Ŵ Roc W ÷ side (100)*1 (40)*1 (40)* (40)*1 (40)* (100)* 0.7 0.3 (40)*1 38 (40)*1 (40)* 79 100)*1 G 0.5 37 29 (40)*1 (40)* 60 76 Head side (40)*¹ 0.7 30 34 50 23 63

The maximum stroke at which the cylinder can be operated under a lateral load

The region that does not exceed the bold solid line represents the allowable lateral load in relation to the cylinder of a given stroke length. In the graph, the range of the broken line shows that the long stroke limit has been exceeded. In this region, as a rule, operate the cylinder by providing a guide along the direction of movement.



C85 Series: Ø8, Ø10, Ø12, Ø16







*1 The data in () are limited by max. stroke length.

Dimensions



∕∂SMC

C85 Series

Dimensions

Double end boss-cut

Rubber bumper: C 85E Bore size - Stroke -







Band mounting (B) Without magnet

With rod boot



Dimensions

Dime	/imensions [mm]																		
Bore size	АМ	BE	с	EE	F	G1	G2	н	(HR)	К	кк	ĸ٧	ĸw	NA	ND	S	sw	(WH)	ZZ
8	12	M12 x 1.25	4	M5 x 0.8	12	7	5	28	13.4	—	M4 x 0.7	19	6	15	12	46	7	16	86
10	12	M12 x 1.25	4	M5 x 0.8	12	7	5	28	14.2	—	M4 x 0.7	19	6	15	12	46	7	16	86
12	16	M16 x 1.5	6	M5 x 0.8	17	8	6	38	14.2	5	M6 x 1	24	8	18.3	16	50	10	22	105
16	16	M16 x 1.5	6	M5 x 0.8	17	8	6	38	14.2	5	M6 x 1	24	8	18.3	16	56	10	22	111
20	20	M22 x 1.5	8	G1/8	20	8	8	44	17	6	M8 x 1.25	32	11	24	22	62	13	24	126
25	22	M22 x 1.5	10	G1/8	22	8	8	50	20	8	M10 x 1.25	32	11	30	22	65	17	28	137

With Rod Boot

With Rod Bo	Nith Rod Boot															[mm]
Item	0.04	<u> </u>	a f	ĸ	ĸĸ						ł	า				
Bore size Stroke		C	e i	n n	ΝΛ	1 te	o 50	51 to ⁻	100	101 to 15	50 151 to	o 200 2	201 to 300	301 to	400 40	1 to 500
20	20	8	36 22	6	M8 x 1.2	5 7	71		84 96		10	09	134	159	9	—
25	22	10	36 22	8	M10 x 1.2	25 7	74			99		12	137	162	2	187
Item								(JH)	(JW)				(Wh)			
Bore size Stroke	1 to 50	51 to 10	0 101 to 150	151 to 200	201 to 300	301 to 400	400 401 to 500 R		Reference	1 to 50	51 to 100	101 to 150	151 to 200	201 to 300	301 to 400	401 to 500
20	12.5	25	37.5	50	75	100	0 — 2		10.5	51	64	76	89	114	139	_
25	12.5	25	37.5	50	75	100	100 125 2		10.5	52	65	77	90	115	140	165

Refer to page 16 of Standard Type Single Rod for details of accessories (rod end, double knuckle joint, floating joint).

11

ISO Standards Air Cylinder: Standard Double Acting, Single Rod **C85** Series

Dimensions





Head cover axial port Band mounting (B) Without magnet

	IA 🛓	
Boss-c	ut/Bas	sic



C85

C85W

C85-S/T

C85K-S/T C85K

C85R

C75

C96Y C55

[mm]

[mm]

Auto Switch Made to Order **Related Products**



Dimensions

Bore size	АМ	BE	С	EE	F	G1	G2	н	(HR)	κ	кк	кν	ĸw	NA	ND	S	sw	(WH)	z
8	12	M12 x 1.25	4	M5 x 0.8	12	7	5	28	13.4	—	M4 x 0.7	19	6	15	12	46	7	16	74
10	12	M12 x 1.25	4	M5 x 0.8	12	7	5	28	14.2	—	M4 x 0.7	19	6	15	12	46	7	16	74
12	16	M16 x 1.5	6	M5 x 0.8	17	8	6	38	14.2	5	M6 x 1	24	8	18.3	16	50	10	22	88
16	16	M16 x 1.5	6	M5 x 0.8	17	8	6	38	14.2	5	M6 x 1	24	8	18.3	16	50	10	22	88
20	20	M22 x 1.5	8	G1/8	20	8	8	44	17	6	M8 x 1.25	32	11	24	22	62	13	24	106
25	22	M22 x 1.5	10	G1/8	22	8	8	50	20	8	M10 x 1.25	32	11	30	22	65	17	28	115

With Rod Boot

Item	A.8.4	<u> </u>		V	VV		h									
Bore size Stroke			; I	n	ΝN	1 t	o 50	51 to 1	00	101 to 15	0 151 to	0 200 2	01 to 300	301 to	400 40	1 to 500
20	20	8 3	6 22	6	M8 x 1.2	5 7	71	84		96	10)9	134	159	9	_
25	22	10 3	6 22	8	M10 x 1.2	25 7	74	87		99	11	2	137	162	2	187
Item				1				(JH)	(JW)				(Wh)			
Bore size Stroke	1 to 50	51 to 100	101 to 150	151 to 200	201 to 300	301 to 400	401 to 500	Reference	Reference	1 to 50	51 to 100	101 to 150	151 to 200	201 to 300	301 to 400	401 to 500
20	12.5	25	37.5	50	75	100	—	23.5	10.5	51	64	76	89	114	139	—
25	12.5	25	37.5	50	75	100	125	23.5	10.5	52	65	77	00	115	140	165

Refer to page 16 of Standard Type Single Rod for details of accessories (rod end, double knuckle joint, floating joint).

12

C85 Series

Dimensions

Bracket is shipped together with the product.

Single foot: C
85N
L
(With mounting bracket)





Double foot: C 85N - M (With mounting bracket)



												[mm]
Bore size	AB	AO	AV	LS	LT	NH	TRJS14	UR	US	(W)	(XL)	(XS)
8	4.5	5	11	68	3.2	16	25	26	35	12.8	73	23.8
10	4.5	5	11	68 (75)	3.2	16	25	26	35	12.8	73 (80)	23.8
12	5.5	6	14	78 (82)	4	20	32	33	42	18	86 (90)	32
16	5.5	6	14	84	4	20	32	33	42	18	92	32
20	6.6	8	17	96	5	25	40	42	54	19	103	36
25	6.6	8	17	99	5	25	40	42	54	23	110	40

(): For air cushion

Refer to page 16 of Standard Type Single Rod for details of accessories (rod end, double knuckle joint, floating joint).

ISO Standards Air Cylinder: Standard Double Acting, Single Rod C85 Series



(WL + Stroke)

							[mm]
Bore size	FB H13	FT	TF	UF	UR	(W)	(WL)
8	4.5	3.2	30	40	22	12.8	65.2
10	4.5	3.2	30	40	22	12.8	65.2 (72.2)
12	5.5	4	40	52	30	18	76 (80)
16	5.5	4	40	52	30	18	82
20	6.6	5	50	66	40	19	91
25	6.6	5	50	66	40	23	98
						(): Fo	or air cushion

UR

Refer to page 16 of Standard Type Single Rod for details of accessories (rod end, double knuckle joint, floating joint).



C85 Series

Dimensions

Rod trunnion: C□85N□-□U (With mounting bracket)









						-
r	Y	h	r	Y	٦	
L	L		L	L	I	
						4

Bore size	TD _{e8}	тм	тт	τΖ	UW	(XV)	(XZ)
8	4	26	6	38	20	13	65
10	4	26	6	38	20	13	65 (72)
12	6	38	8	58	25	18	76 (80)
16	6	38	8	58	25	18	82
20	6	46	8	66	32	20	90
25	6	46	8	66	32	24	97

(): For air cushion

Clevis: C□85N□ – □N (With mounting bracket)



										[mm]
Bore size	АВ	AE	AO	AU	СD н9	LG	LT	NH	TR	(XC)
8	4.5	8.1	1.5	13.1	4	20	2.5	24	12.5	64
10	4.5	8.1	1.5	13.1	4	20	2.5	24	12.5	64 (71)
12	5.5	12.1	2	18.5	6	25	3.2	27	15	75 (79)
16	5.5	12.1	2	18.5	6	25	3.2	27	15	82
20	6.6	16.1	4	24.1	8	32	4	30	20	95
25	6.6	16.1	4	24.1	8	32	4	30	20	104

(): For air cushion

Refer to page 16 of Standard Type Single Rod for details of accessories (rod end, double knuckle joint, floating joint).

C85 Series Dimensions of Accessories

Rod End





											[mm]
Bore size	Part no.	b1	bз	dH7	d 6	d7	h	Ι	lз	d3	α°
8	KJ4D	8	6.0	5	18	11	27	10	10	M4 x 0.7	13
10	KJ4D	8	6.0	5	18	11	27	10	10	M4 x 0.7	13
12	KJ6D	9	6.75	6	20	13	30	12	11	M6 x 1	13
16	KJ6D	9	6.75	6	20	13	30	12	11	M6 x 1	13
20	KJ8D	12	9	8	24	16	36	16	13	M8 x 1.25	14
25	KJ10D	14	10.5	10	28	19	43	20	15	M10 x 1.25	13

Double Knuckle Joint



										[mm]
Bore size	Part no.	b	С	d	f	g	j	k	е	I
8	GKM4-8	4	8	16	4	8	8	11	M4 x 0.7	21
10	GKM4-8	4	8	16	4	8	8	11	M4 x 0.7	21
12	GKM6-12	6	12	24	6	12	10	18	M6 x 1	31
16	GKM6-12	6	12	24	6	12	10	18	M6 x 1	31
20	GKM8-16	8	16	32	8	16	14	23	M8 x 1.25	42
25	GKM10-20	10	20	40	10	20	18	27	M10 x 1.25	52

Floating Joint: JA

н



In the case of dimension without C



														[mm]
Bore size	Part no.	Nominal thread dia.	l Pitch	Α	в	С	D	Е	F	G	н	Max. screw-in depth P	Allowable eccentricity U	Max. operating tension and compression power [kN]
8, 10	JA10-4-070	4	0.7	26	9	10	12	1.5	4	4	7	5.5	0.5	0.054
12, 16	JA15-6-100	6	1	34.5	12.5	14	16	2	6	5	10	7	0.5	0.123
20	JA20-8-125	8	1.25	44	17.5	—	21	4.5	7	7	13	8	0.5	1.1
25	JA30-10-125	10	1.25	49.5	19.5	_	24	5	8	8	17	9	0.5	2.5

C85

16

Related Products

C85/C75 Series Auto Switch Mounting

Auto Switch Proper Mounting Position (Detection at stroke end) and Mounting Height



Auto Switch Mounting C85/C75 Series

Auto Switch Proper Mounting Position (Detection at stroke end) and Mounting Height



P-10-2 2023-05

C85/C75 Series

Auto Switch Proper Mounting Position (Detection at stroke end) and Mounting Height

Applicable series: CD85 (Double acting, Single rod), CD85W (Double acting, Double rod), CD85K (Non-rotating rod), CD85R (Direct mount)

Auto Switch Proper Mounting Position [mm]

Auto	Band mounting										
Bore	D-M9 D-M9 D-M9 D-M9 D-M9	D-M9 D-M9 V D-M9 WV D-M9 A D-M9 A D-M9 A V		9⊡ 9⊡V	D-H7 D-H7 D-H7 D-H7 D-H7	70 7C 70W 7BA 7NF	D-C7□ D-C80 D-C73C D-C80C				
size	Α	В	Α	В	Α	В	Α	В			
8	6.5	6.5	—	—	2	2	3	3			
10	6.5 (7)	6.5 (7)	—	—	2 (2.5)	2 (2.5)	3 (3.5)	3 (3.5)			
12	7.5 (8.5)	7.5 (8.5)	_	_	3 (4)	3 (4)	4 (5)	4 (5)			
16	7.5 (8.5)	13.5 (10.5) [7.5]	3.5 (4.5)	9.5 (6.5) [3.5]	3 (4)	9 (6) [3]	4 (5)	10 (7) [4]			
20	10.5 (8.5)	9.5 (7.5)	6.5 (4.5)	5.5 (3.5)	6 (4)	5 (3)	7 (5)	6 (4)			
25	12 (10)	11 (9)	8 (6)	7 (5)	7.5 (5.5)	6.5 (4.5)	8.5 (6.5)	7.5 (5.5)			

* The value in () is in cases with air cushion.

The value in [] is in cases of CD85F16, CD85Y.
D-A9
 type cannot be mounted on bore size ø8, ø10,

 D-A9 type cannot be mounted on bore size Ø8, Ø10 or Ø12 cylinder.

* Adjust the auto switch after confirming the operating conditions in the actual setting.

[mm]

Auto Switch Mounting Height

Auto		Band mounting											
Bore	D-M9 D-M9 D-M9 D-M9 D-A9 *1	D-M9 U D-M9 WV D-M9 AV D-A9 V*1	D-H7 D-H7 D-H7BA D-H7NF D-C7 D-C80	D-H7C	D-C73C D-C80C								
size	Hs	Hs	Hs	Hs	Hs								
8	16	16.5	17	19	18.5								
10	17.5	18	18	20	19.5								
12	18.5	19	19	21	20.5								
16	20.5	21	21	23	22.5								
20	24.5	24.5	24.5	25.5	25								
25	27	27	27	27.5	27								

*1 D-A9□(V) type cannot be mounted on bore size ø8, ø10, or ø12 cylinder.

\ Auto					Rail m	ounting			-	
Bore	D-M9 D-M9 D-M9 D-M9 D-M9 D-M9	□ □V □WV □A □AV	D-A D-A	9□ 9□V	D-F7 D-F7 D-F7 D-F7 D-F79 D-F78 D-F78 D-F78 D-A72 D-A80 D-A730	//J79 W/J79W IV IWV F/J79C A AV /A7⊡H H C/A80C	D-4 D-4	473 480	D-A	79W
size \	Α	В	Α	В	Α	В	Α	В	Α	В
8	5	5			4	4	3.5	3.5	—	—
10	5 (5.5)	5 (5.5)	—	—	4 (4.5)	4 (4.5)	3.5 (4)	3.5 (4)	_	—
12	6 (7)	6 (7)	—	_	5 (6)	5 (6)	4.5 (5.5)	4.5 (5.5)	_	_
16	6 (7)	12 (9) [6]	3.5 (4.5)	9.5 (6.5) [3.5]	5 (6)	11 (8) [5]	4.5 (5.5)	10.5 (7.5) [4.5]	2 (3)	8 (5) [2]
20	_	_	6.5 (4.5)	5.5 (3.5)	8 (6)	7 (5)	7.5 (5.5)	6.5 (4.5)	5 (3)	4 (2)
25	_	_	8 (6)	7 (5)	9.5 (7.5)	8.5 (6.5)	9 (7)	8 (6)	6.5 (4.5)	5.5 (3.5)

* The value in () is in cases with air cushion.

* The value in [] is in cases of CD85F16, CD85Y.

D-A9□(V) and A79W types cannot be mounted on bore size ø8, ø10, or ø12 cylinder.
 D-M9□(V), M9□W(V), and M9□A(V) types cannot be mounted on bore size ø20 or ø25

cylinder. * No rail mounting is available with CD85R (direct mount type).

* Adjust the auto switch after confirming the operating conditions in the actual setting.

							[mm]				
\ Auto		Rail mounting									
Bore	D-M9 *1 D-M9 V D-M9 W D-M9 WV D-M9 AV D-M9 AV D-A9 *2 D-A9 V	D-F7 D-J79 D-F7 W D-J79W D-F79F D-F7BA D-A7 H D-A80H	D-F7□V D-F7□WV D-F7BAV	D-J79C	D-A7□ D-A80	D-A73C D-A80C	D-A79W				
size \	Hs	Hs	Hs	Hs	Hs	Hs	Hs				
8	16	16	19	21	16	22.5	—				
10	17	17	20	22	17	23.5	—				
12	20.5	20.5	23	25	19.5	26.5	—				
16	20.5	20.5	23	25	19.5	26.5	22				
20	23.5	23.5	26	29	22.5	29.5	25				
25	26.5	26.5	29	32	25.5	32.5	28				

*1 D-M9□(V), M9□W(V), and M9□A(V) types cannot be mounted on bore size ø20 or ø25 cylinder.

*2 D-A9 \Box (V) and A79W types cannot be mounted on bore size ø8, ø10, or ø12 cylinder.

*3 No rail mounting is available with CD85R (direct mount type).

[mm]

Auto Switch Proper Mounting Position (Detection at stroke end) and Mounting Height

Applicable series: CD75 (Double acting, Single rod), CD75W (Double acting, Double rod), CD75K (Non-rotating rod), CD75R (Direct mount)

Auto Switch Proper Mounting Position

Auto Sw	iuto Switch Proper Mounting Position [mm]														
Auto switch model Bore	D-M9 D-M9 D-M9 D-M9 D-M9 D-M9	 V W WV A AV	D-A D-A	9□ 9□V	D-C D-C D-C D-C	7⊡ 80 73C 80C	D-4 D-4	\73 \80	D-A7 H// D-A73C D-F7 // D-F7 V D-J79C D-F79F	A80H/A72 C/A80C J79 V/J79W /F7BAL	D-H7 D-H7 D-H7 D-H7 D-H7	′□ ′C ′□W ′BAL ′NF	D-A	79W	
size \	Α	B	Α	В	A	В	Α	В	A	B	Α	В	Α	В	
32	11.5	10.5	7.5	6.5	8 (6)	7 (5)	8.5 (6.5)	7.5 (5.5)	9 (7)	8 (6)	7 (5)	6 (4)	6 (4)	5 (3)	
40	17.5	15.5	13.5	11.5	14 (11)	12 (9)	14.5 (11.5)	12.5 (9.5)	15 (12)	13 (10)	13 (10)	11 (8)	12 (9)	10 (7)	

* The value in () is for air cushion.

* The above-mentioned value is a guide for auto switch mounting positions for stroke end detection.

Adjust the auto switch after confirming the operating conditions in the actual setting.

* A/B dimensions are the distance from the cover to the end surface of the auto switch.

Auto Switch Mounting Height

Auto Sw	uto Switch Mounting Height [mm]										
Auto switch model Bore	D-M9 D-M9 V D-M9 WV D-M9 WV D-M9 AV D-M9 AV D-A9 V	D-C7□/C80 D-H7□ D-H7□W D-H7BAL D-H7NF	D-C73C D-C80C	D-A7□ D-A80	D-A7⊟H D-A80H	D-F7□/J79 D-F7□W D-J79W D-F7BAL D-F79F	D-A73C D-A80C	D-H7C	D-A79W	D-J79C	
size \	Hs	Hs	Hs	Hs	Hs	Hs	Hs	Hs	Hs	Hs	
32	30.5	30.5	31	30	30.5	30	36	31.5	31.5	34.5	
40	35.5	35.5	35	34.5	35	34.5	40.5	35.5	36	39	

C85/C75 Series

Auto Switch Proper Mounting Position (Detection at stroke end) and Mounting Height

[mm]

Applicable series: CD85□-□S (Single acting, Spring return)

		111000	n mount	<u></u>		[11111
A	Auto switch	Bore	A	dimension	IS	Р
	model	size	5 to 50 st	51 to 100 st	101 to 150 st	D
		8	18.5	18.5	18.5	6.5
		10	16.5	16.5	16.5	6.5
	D-M9	12	18	18	18	7.5
	D-M9⊟V D-M9⊟W D-M9⊟WV	16	18	33.5	49	13.5 [7.5]
	D-M9⊡A D-M9⊡AV	20	10.5 (35.5)	60.5	85.5	9.5
	D-WI9DAV	25	10.5 (35.5)	60.5	85.5	11
	D-A9□	16	14	29.5	45	9.5 [3.5]
		20	6.5 (31.5)	56.5	81.5	5.5
ing		25	6.5 (31.5)	56.5	81.5	7
nut		8	14	14	14	2
С ш	nou	10	12	12	12	2
pu	D-H7 □	12	13.5	13.5	13.5	3
Ba	D-H7C D-H7⊟W	16	13.5	29	44.5	9 [3]
	D-H7BA D-H7NF	20	6 (31)	56	81	5
		25	6 (31)	56	81	6.5
		8	15	15	15	3
		10	13	13	13	3
		12	14.5	14.5	14.5	4
	D-C70 D-C80	16	14.5	30	45.5	10 [4]
	D-C80C	20	7 (32)	57	82	6
		25	7 (32)	57	82	7.5

Auto Switch Proper Mounting Position	
--------------------------------------	--

						[mm]
	Auto switch	Bore	A	dimension	s	П
	model	size	5 to 50 st	51 to 100 st	101 to 150 st	D
	D-M9□	8	17	17	17	5
	D-M9⊡V	10	15	15	15	5
	D-M9⊟W D-M9⊟WV	12	16.5	16.5	16.5	6
	D-M9⊟A D-M9⊟AV	16	16.5	32	47.5	12 [6]
		16	12.5	28	43.5	8 [2]
	D-A9⊟ D-A9⊟V D-A79W	20	5 (30)	55	80	4
D-A7	DAISH	25	5 (30)	55	80	5.5
	D-F7□/J79	8	16	16	16	4
	D-F7⊡W	10	14	14	14	4
Inti	D-J79₩ D-F7⊡V	12	15.5	15.5	15.5	5
ail mot	D-F7⊟WV D-F79F/J79C	16	15.5	31	46.5	11 [5]
č	D-F7BA D-F7BAV D-A72	20	8 (33)	58	83	7
	D-A7⊡H/A80H D-A73C/A80C	25	8 (33)	58	83	8.5
		8	15.5	15.5	15.5	3.5
		10	13.5	13.5	13.5	3.5
		12	15	15	15	4.5
D-A D-A	D-A73	16	15	30.5	46	10.5 [4.5]
	D AUU	20	7.5 (32.5)	57.5	82.5	6.5
		25	7.5 (32.5)	57.5	82.5	8

The value in () is in cases of non-rotating.
The value in [] is in cases of CD85F16, CD85Y.

* D-A9□(V) and A79W types cannot be mounted on bore size ø8, ø10, or ø12 cylinder.

When mounting a rail on bore size ø20 or ø25 cylinder, D-M9□(V), M9□W(V) and M9□A(V) types cannot be mounted.

* Adjust the auto switch after confirming the operating conditions in the actual setting.

A	uto Sv	witch Mounting Height	[mm]
Ν	Auto	Band mounting	

\ Auto		Ba	nd mount	ing	
Bore	D-M9 D-M9 W D-M9 A D-A9 *1	D-M9 V D-M9 WV D-M9 AV D-A9 V*1	D-H7 D-H7 D-H7BA D-H7NF D-C7 D-C80	D-H7C	D-C73C D-C80C
size \	Hs	Hs	Hs	Hs	Hs
8	16	16.5	17	19	18.5
10	17.5	18	18	20	19.5
12	18.5	19	19	21	21
16	20.5	21	21	23	23
20	24.5	24.5	24.5	25	25
25	27	27	27	27.5	27.5

*1 D-A9 \Box (V) type cannot be mounted on bore size ø8, ø10, or ø12 cylinder.

							[mm]
Auto			F	lail mountin	g		
switch model	D-M9 *1 D-M9 V D-M9 W D-M9 W D-M9 A D-M9 A D-M9 AV D-A9 *2 D-A9 V	D-F7 D-J79 D-F7 W D-J79W D-F79F D-F7BA D-A7 H D-A80H	D-F7□V D-F7□WV D-F7BAV	D-J79C	D-A7□ D-A80	D-A73C D-A80C	D-A79W
size \	Hs	Hs	Hs	Hs	Hs	Hs	Hs
8	16	16	19	21	16	22.5	—
10	17	17	20	22	17	23.5	—
12	20.5	20.5	23	25	19.5	26.5	_
16	20.5	20.5	23	25	19.5	26.5	22
20	23.5	23.5	26	29	22.5	29.5	25
25	26.5	26.5	29	32	25.5	32.5	28
							<u> </u>

*1 D-M9□(V), M9□W(V), and M9□A(V) types cannot be mounted on bore size ø20 or ø25 cylinder.

*2 D-A9□(V) and A79W types cannot be mounted on bore size ø8, ø10, or ø12 cylinder.

Auto Switch Proper Mounting Position (Detection at stroke end) and Mounting Height

Applicable series: CD75□-□S (Single acting, Spring return)

Auto Switch Proper Mounting Position

Auto Switch I	Proper	Mountin	g Positio	n			[mm]
Auto switch	Bore		S	ingle acting,	Spring retur	'n	
model	size		-	dimension	S		в
		1 to 50 st	51 to 100 st	101 to 150 st	151 to 200 st	151 to 200 st	
D-M9□ D-M9□V D-M9□W	32	11.5 (36.5)	61.5	86.5	111.5	136.5	10.5
D-M9⊟WV D-M9⊟A D-M9⊟AV	40	16.5 (41.5)	66.5	91.5	116.5	141.5	15.5
D-A9□	32	7.5 (32.5)	57.5	82.5	107.5	132.5	6.5
D-A9⊟V	40	12.5 (37.5)	62.5	87.5	112.5	137.5	11.5
D-C7□/C80	32	8 (33)	58	83	108	—	7
D-C73C/C80C	40	13 (38)	63	88	113	138	12
D-A73	32	8.5 (33.5)	58.5	83.5	108.5	—	7.5
D-A80	40	13.5 (38.5)	63.5	88.5	113.5	138.5	12.5
D-A72/A7 H/A80H D-A73C/A80C D-F7 //F7 W	32	9 (34)	59	84	109	_	8
D-F7□WV D-J79C D-F7BAL, D-F79F	40	14 (39)	64	89	114	139	13
D-470WI	32	6 (31)	56	81	106	—	5
DAISWE	40	11 (36)	61	86	111	136	10
D-H7□/H7C/H7□W	32	7 (32)	57	82	107	—	6
D-H7BAL, D-H7NF	40	12 (37)	62	87	112	137	11

The value in () is for air cushion. *

The above-mentioned value is a guide for auto switch mounting positions for stroke end detection. Adjust the auto switch after confirming the operating conditions in the actual setting.

* A/B dimensions are the distance from the cover to the end surface of the auto switch.

Auto Switch Mounting Height

Auto Switc	h Mountin	ng Height								[mm]
Auto switch model Bore	D-M9 D-M9 D-M9 WV D-M9 AV D-M9 AV D-M9 AV D-A9 V	D-C7□/C80 D-H7□ D-H7□W D-H7BAL D-H7NF	D-C73C D-C80C	D-A7⊡ D-A80	D-A7⊟H D-A80H	D-F7□/J79 D-F7□W D-J79W D-F7BAL D-F79F	D-A73C D-A80C	D-H7C	D-A79W	D-J79C
size	Hs	Hs	Hs	Hs	Hs	Hs	Hs	Hs	Hs	Hs
32	30.5	30.5	31	30	30.5	30	36	31.5	31.5	34.5
40	35.5	35.5	35	34.5	35	34.5	40.5	35.5	36	39

C85/C75 Series

Auto Switch Proper Mounting Position (Detection at stroke end) and Mounting Height

Applicable series: CD85□-□T (Single acting, Spring extend)

Αι	Auto Switch Proper Mounting Position [mm												
	Auto switch	Bore	•	E	IS								
	model	size	A	5 to 50 st	51 to 100 st	101 to 150 st							
		8	6.5	31	31	31							
	D-M9□	10	6.5	29	29	29							
	D-M9□V	12	7.5	31	31	31							
	D-M9 D-M9 D-M9 A D-M9 AV	16	7.5	36 [30]	62 [56]	88 [82]							
		20	10.5	34.5	59.5	84.5							
		25	12	34.5	59.5	84.5							
	D-A9□	16	3.5	32 [26]	58 [52]	84 [80]							
	D-A9⊡V	20	6.5	30.5	55.5	80.5							
ing		25	8	30.5	55.5	80.5							
nut		8	2	26.5	26.5	26.5							
le	D-H7□	10	2	24.5	24.5	24.5							
g	D-H7C	12	3	26.5	26.5	26.5							
Ba	D-H7⊡W D-H7BA	16	3	31.5 [25.5]	57.5 [51.5]	83.5 [77.5]							
	D-H7NF	20	6	30	55	80							
		25	7.5	30	55	80							
		8	3	27.5	27.5	27.5							
		10	3	25.5	25.5	25.5							
		12	4	27.5	27.5	27.5							
	D-C73C	16	4	32.5 [26.5]	58.5 [52.5]	84.5 [78.5]							
	D-C80C	20	7	31	56	81							
		25	8.5	31	56	81							

	Auto switch	Bore	٨	B dimensions			
	model	size	A	5 to 50 st	51 to 100 st	101 to 150 st	
	D-M9□	8	5	29.5	29.5	29.5	
	D-M9⊡V	10	5	27.5	27.5	27.5	
	D-M9⊟W D-M9⊟WV	12	6	29.5	29.5	29.5	
	D-M9⊟A D-M9⊟AV	16	6	34.5 [28.5]	60.5 [54.5]	86.5 [80.5]	
		16	2	30.5 [24.5]	56.5 [50.5]	82.5 [76.5]	
		20	5	29	54	79	
	D-A15W	25	6.5	29	54	79	
_	D-F7□/J79	8	4	28.5	28.5	28.5	
Iting	D-F7⊟W D-J79W	10	4	26.5	26.5	26.5	
uno		12	5	28.5	28.5	28.5	
Rail m	D-F79F/J79C D-F7BA D-F7BAV	16	5	33.5 [27.5]	59.5 [53.5]	85.5 [79.5]	
	D-A72 D-A7⊟H/A80H	20	8	32	57	82	
	D-A73C/A80C	25	9.5	32	57	82	
		8	3.5	28	28	28	
		10	3.5	26	26	26	
	D-473	12	4.5	28	28	28	
	D-A80	16	4.5	33 [27]	59 [53]	85 [79]	
		20	7.5	31.5	56.5	81.5	
		25	9	31.5	56.5	81.5	

[mm]

* The value in [] is in cases of CD85F16, CD85Y.

* D-A9□(V) and A79W types cannot be mounted on bore size ø8, ø10, or ø12 cylinder.

* When mounting a rail on bore size ø20 or ø25 cylinder, D-M9□(V), M9□W(V) and M9□A(V) types cannot be mounted.

[mm]

* Adjust the auto switch after confirming the operating conditions in the actual setting.

Auto Switch Mounting Height

Auto	Auto Band mounting											
switch model	D-M9 D-M9 D-M9 D-M9 A D-A9 *1	D-M9 U D-M9 WV D-M9 AV D-A9 V*1	D-H7 D-H7 D-H7BA D-H7NF D-C7 D-C80	D-H7C	D-C73C D-C80C							
size \	Hs	Hs	Hs	Hs	Hs							
8	16	16.5	17	19	18.5							
10	17.5	18	18	20	19.5							
12	18.5	19	19	21	20.5							
16	20.5	21	21	23	22.5							
20	24.5	24.5	24.5	25.5	25							
25	27	27	27	27.5	27							

*1 D-A9□(V) type cannot be mounted on bore size ø8, ø10, or ø12 cylinder.

							[mm]					
Auto Rail mounting												
Bore	D-M9 *1 D-M9 V D-M9 W D-M9 WV D-M9 A D-M9 A D-M9 AV D-A9 *2 D-A9 V	D-F7 D-J79 D-F7 W D-F79W D-F79F D-F7BA D-A7 H D-A80H	D-F7□V D-F7□WV D-F7BAV	D-J79C	D-A7□ D-A80	D-A73C D-A80C	D-A79W					
size \	Hs	Hs	Hs	Hs	Hs	Hs	Hs					
8	16	16	19	21	16	22.5	—					
10	17	17	20	22	17	23.5	—					
12	20.5	20.5	23	25	19.5	26.5	—					
16	20.5	20.5	23	25	19.5	26.5	22					
20	23.5	23.5	26	29	22.5	29.5	25					
25	26.5	26.5	29	32	25.5	32.5	28					
		INA and MC		a connot ha	mounted o	n hara aiza	~00 or ~0E					

*1 D-M9□(V), M9□W(V), and M9□A(V) types cannot be mounted on bore size ø20 or ø25 cylinder.

*2 D-A9 \Box (V) and A79W types cannot be mounted on bore size ø8, ø10, or ø12 cylinder.

[mm]

Auto Switch Proper Mounting Position (Detection at stroke end) and Mounting Height

Applicable series: CD75□-□T (Single acting, Spring extend)

Auto Switch Proper Mounting Position

Auto owitch	Poro		Si	ngle acting,	Spring exte	nd					
Auto switch	Bore	•	B dimensions								
model	5120	A	1 to 50 st	51 to 100 st	101 to 150 st	151 to 200 st	151 to 200 st				
D-M9□ D-M9□V D-M9□W	32	11.5	35.5	60.5	85.5	110.5	_				
D-M9□WV D-M9□A D-M9□AV	40	16.5	40.5	65.5	90.5	115.5	140.5				
D-A9□	32	7.5	31.5	56.5	81.5	106.5					
D-A9□V	40	12.5	36.5	61.5	86.5	111.5	136.5				
D-C7□/C80	32	8	32	57	82	107	—				
D-C73C/C80C	40	13	37	62	87	112	137				
D-A73	32	8.5	32.5	57.5	82.5	107.5	—				
D-A80	40	13.5	37.5	62.5	87.5	112.5	137.5				
D-A72/A7□H/A80H D-A73C/A80C D-F7□/F7□W D_I72/I70W	32	9	33	58	83	108	_				
D-579/379W D-F7□WV D-J79C D-F7BAL, D-F79F	40	14	38	63	88	113	138				
D_A70W/I	32	6	30	55	80	105	_				
D-A/SWL	40	11	35	60	85	110	135				
D-H7□/H7C/H7□W	32	7	31	56	81	106	_				
D-H7BAL, D-H7NF	40	12	36	61	86	111	136				

The value in () is for air cushion. *

The above-mentioned value is a guide for auto switch mounting positions for stroke end detection.

Adjust the auto switch after confirming the operating conditions in the actual setting.

A/B dimensions are the distance from the cover to the end surface of the auto switch.

Auto Switch Mounting Height

Auto Sw	Auto Switch Mounting Height [mm]													
Auto switch model Bore	D-M9 D-M9 V D-M9 WV D-M9 AV D-M9 AV D-M9 AV D-A9 U-A9 V	D-C7□/C80 D-H7□ D-H7□W D-H7BAL D-H7NF	D-C73C D-C80C	D-A7□ D-A80	D-A7⊡H D-A80H	D-F7□/J79 D-F7□W D-J79W D-F7BAL D-F79F	D-A73C D-A80C	D-H7C	D-A79W	D-J79C				
size \	Hs	Hs	Hs	Hs	Hs	Hs	Hs	Hs	Hs	Hs				
32	30.5	30.5	31	30	30.5	30	36	31.5	31.5	34.5				
40	35.5	35.5	35	34.5	35	34.5	40.5	35.5	36	39				

C85/C75 Series

C85: Ø8, Ø10, Ø12, Ø16 n: Number of auto switches [mm]										
				Num	ber of auto switches					
	Auto switch		2	2	r	1				
	model	1	Different	Same	ø8 to	0.016				
			surfaces	surface	Different surfaces	Same surface				
ing	D-M9 D-M9 D-M9 D-M9 D-M9 A D-M9 AV D-M9 AV D-A9 V	10	* ¹ 15	* ¹ 45	15 + 35 <u>(n - 2)</u> (n = 2, 4, 6···)	45 + 15 (n - 2) (n = 2, 4, 6…)				
nd mount	D-C7□ D-C80	10	15	50	$15 + 40 \frac{(n-2)}{2}$ (n = 2, 4, 6)	$\begin{array}{l} 50+20\;(n-2)\\(n=2,4,6\cdots)\end{array}$				
Bar	D-H7□ D-H7□W D-H7BA D-H7NF	10	15	60	$15 + 45 \frac{(n-2)}{2}$ (n=2, 4, 6)	60 + 22.5 (n - 2) (n = 2, 4, 6…)				
	D-H7C D-C73C D-C80C	10	15	65	$15 + 50 \frac{(n-2)}{2}$ (n = 2, 4, 6)	50 + 27.5 (n - 2) (n = 2, 4, 6…)				
	D-M9⊡V D-F7⊡V D-J79C	5	_	5	_	10 + 10 (n - 2) (n = 4, 6…)				
	D-F7□ D-J79	5	—	5	—	15 + 15 (n – 2) (n = 4, 6···)				
	D-A9 □ V *2	5	_	10	—	10 + 15 (n - 2) (n = 4, 6···)				
	D-A7□ D-A80 D-A73C D-A80C	5	_	10	_	15 + 10 (n - 2) (n = 4, 6…)				
unting	D-A7⊟H D-A80H	5	_	10	_	15 + 15 (n – 2) (n = 4, 6…)				
ail mot	D-M9□ D-A9□*²	10	_	10	—	15 + 15 (n – 2) (n = 4, 6…)				
Ŗ	D-F7□WV D-F7BAV D-A79W*2	10		15	_	10 + 15 (n - 2) (n = 4, 6…)				
	D-M9⊡WV D-M9⊡AV	10		15	_	15 + 15 (n – 2) (n = 4, 6…)				
	D-F7⊟W D-J79W D-F7BA	10	_	15	_	15 + 20 (n - 2) (n = 4, 6…)				
	D-M9□W	15		15	_	15 + 15 (n – 2) (n = 4, 6…)				
	D-M9□A	15	_	20	—	20 + 15 (n - 2) (n = 4, 6···)				

Minimum Stroke for Auto Switch Mounting

	C	C85: Ø20, Ø25 n: Number of auto switches [mm]											
					Num	per of auto switch	es						
		Auto switch		2	2	r	ו						
		model	1	Different	Same	ø20,	ø25						
				surfaces	surface	Different surfaces	Same surface						
	ing	D-M9 D-M9 V D-M9 W D-M9 A D-M9 AV D-M9 AV D-A9 V	10	15 ^{*1}	45 ^{*1}	$15 + 45 \frac{(n-2)}{2}$	45 + 45 (n – 2) (n = 2, 4, 6…)						
	Band moun	D-C7□ D-C80	10	15	50	(n = 2, 4, 6···)	50 + 45 (n - 2) (n = 2, 4, 6…)						
		D-H7□ D-H7□W D-H7BA D-H7NF	10	15	60		60 + 45 (n - 2) (n = 2, 4, 6···)						
		D-H7C D-C73C D-C80C	10	15	65	$15 + 50 \frac{(n-2)}{2}$ (n = 2, 4, 6)	65 + 50 (n - 2) (n = 2, 4, 6…)						
		D-F7⊡V D-J79C	5	_	5	_	10 + 10 (n - 2) (n = 4, 6…)						
		D-F7⊡ D-J79	5	_	5	_	15 + 15 (n – 2) (n = 4, 6…)						
		D-A9□ D-A9□V	5	_	10	_	10 + 15 (n – 2) (n = 4, 6…)						
	mounting	D-A7□ D-A80 D-A73C D-A80C	5	_	10	_	15 + 10 (n - 2) (n = 4, 6…)						
	Rail	D-A7⊟H D-A80H	5	-	10	—	15 + 15 (n – 2) (n = 4, 6…)						
		D-F7⊟WV D-F7BAV D-A79W	10	_	15	_	10 + 15 (n - 2) (n = 4, 6…)						
		D-F7⊟W D-J79W D-F7BA	10	_	15	_	15 + 20 (n - 2) (n = 4, 6···)						

*1 Auto switch mounting (With the stroke range within the below, an adjustment is required as shown in the chart below).



*2 D-A9□(V) and A79W types cannot be mounted on bore size ø8, ø10, or ø12 cylinder.

* When mounting a rail on bore size ø20 or ø25 cylinder, D-M9□(V), M9□W(V) and M9□A(V) types cannot be mounted.



C7	75: Ø32, Ø40 n: Number of auto switches [mm									
				Num	ber of auto switch	es				
	Auto switch		2		n					
	model	1	Different	Same	ø32,	ø40				
			surfaces	surface	Different surfaces	Same surface				
ng	D-C73, D-C80 D-H7A1, D-H7A2 D-H7B	10	15	50		50 + 45 (n – 2)				
nd mountii	D-C73C D-C80C D-H7C	10	15	65	$15 + 45 \frac{(n-2)}{2}$ (n = 2, 4)	65 + 50 (n - 2)				
Ba	D-H7NW D-H7PW D-H7BW	10	15	75	1	75 + 55 (n – 2)				
mounting	D-A73, D-A80 D-A73H, D-A80H D-A73C, D-A80C D-F79, D-J79 D-F7P, D-J79C	5	_	10	_	$15 + 35 \frac{(n-2)}{2}$				
Rail	D-A79W, D-F79W D-F7PW D-J79W	10	_	15	_	(n = 2, 4…)				

Minimum Stroke for Auto Switch Mounting

Operating Range

									[mm]
					Bore	size			
Au	o switch model	8	10	12	16	20	25	32	40
Band mounting	D-M9□ D-M9□V D-M9□W D-M9□WV D-M9□A D-M9□AV	2	2.5	2.5	3	3	3	3	3
	D-A9□*1 D-A9□V*1	_	_	—	7	6	6	6	6
	D-H7□ D-H7□W D-H7BA D-H7NF	3	3	3	4	4	4	4.5	5
	D-H7C	8	8	8	9	7	8.5	9	10
	D-C7□/C80 D-C73C/C80C	7	7	7	7	7	8	8	8
	D-M9 D-M9 W/M9 WV*2, 3 D-M9 A/M9 AV*2, 3	2.5	3	3.5	3.5	_	_	_	_
	D-A9□* ^{1, 3} D-A9□V* ^{1, 3}	_	_	—	6.5	5.5	6	—	—
Rail mounting	D-F7□/J79 D-F7□V/J79C D-F7□W/J79W D-F7□WV D-F79F D-F78A/F7BAV	5	5	6	5	5	6	4.5	4.5
	D-A7□/A80 D-A7□H/A80H D-A73C/A80C	8	8	9	9	7	7	7.5	7.5
	D-A79W*1	-	_	—	13	10	10.5	11.5	11.5

*1 D-A9□(V) and A79W types cannot be mounted on bore size ø8, ø10, or ø12 cylinder.

*2 When mounting a rail on bore size ø20 or ø25 cylinder, D-M9□(V), M9□W(V) and M9□A(V) types cannot be mounted.
*3 When mounting a rail on bore size ø32 or ø40 cylinder, D-M9□(V), M9□W(V), M9□A(V) and A9□(V) types cannot be mounted.

* Values which include hysteresis are for guideline purposes only, they are not a guarantee (assuming approximately ±30% dispersion) and may change substantially depending on the ambient environment.

114

C85/C75 Series

Auto Switch Mounting Bracket/Set Part Nos.

A				C85 S	Series			C75 S	Series
Auto switch	Auto switch model				Bore siz	ze [mm]			
mounting	, allo switch model	ø 8	ø 10	ø 12	ø16	ø 20	ø 25	ø 32	ø 40
	D-M9□(V)	*1	*1 DIC 010	*1	*1	*1	*1	*1	*1
	D-M9⊟W(V) D-A9⊡(V)*7	(A set of a, b, c, d, g)	(A set of a, b, c, d, g)	(A set of a, b, c, d, g)	(A set of a, b, c, d, g)	(A set of a, b, c, d)	(A set of a, b, c, d)	(A set of a, b, c, d)	(A set of a, b, c, d)
	D-M9□A(V)*2	BJ6-008S	BJ6-010S	BJ6-012S	BJ6-016S	BM5-020S	BM5-025S	BM5-032S	BM5-040S
	When the bore si	r (A set of a, b, c, e , i , y)	(A Set 01 a, D, C, e ,1 ,9)	(A set of a, b, c, e , r, y)	(A set of a, b, c, e , i , g)	hen the hore si	(A set of a, b, c, e, f)	(A set of a, b, c, e, i)	(A Set 01 a, D, C, e, I)
	Sw	vitch bracket		d (Low carbon ste	el wire rod)	Switch bracket		Auto switch m	ounting screw
	Bore size: 8 mm	Bore size: 10 to	16 mm	f (Stainless steel))a	Transparent (Nylon)*	1 6,7	d (Low carbon s	teel wire rod)
*3	 a Transparent blue (Ny e Black (PBT) 	White (PBT)	/lon) 6,7	9 Protective of	cover e	White (PBT)			<u>ه، ا</u>
*4 Band					p	Switch holder (Zinc)			
mounting	b	witch holder (Zinc)		Charles and the second		13	(A) + (),		
	c Auto switch mounting band (3) For BJ6 (With switch installed) c Auto switch mounting band (3) For BJ6								/ith switch installed)
	D-H7□ D-H7□W D-H7NF D-C7□/C80 D-C73C/C80C	BJ2-008 (A set of c, d ,g)	BJ2-010 (A set of c, d ,g)	BJ2-012 (A set of c, d ,g)	BJ2-016 (A set of c, d ,g)	BM2-020A (A set of c and b)	BM2-025A (A set of c and b)	BM2-032A (A set of c and b)	BM2-040A (A set of c and b)
	D-H7BA	BJ2-008S (A set of c and f)	BJ2-010S (A set of c and f)	BJ2-012S (A set of c and f)		BMA2-020AS (A set of c and f)	BMA2-025AS (A set of c and f)	BMA2-032AS (A set of c and f)	BMA2-040AS (A set of c and f)
D-M9□(V)*8 BQ2-012 (S) D-M9□A(V)*8 (A set of h and i) D-A9□(V)*7 (A set of h and i)									
*5		h Auto sw	itch mounting bra	icket	Set screw				
Rail		Brad	ket fixing screw		ondoody				
linearing		(Cyl	inder accessory)	i Auto	switch mounting	corow			
			0	(Cylinder a	accessory)				
of Cines	ha auditah husaliat fa	ومنافعت ومعرام مرما و		lan) are affecte	مرمد مريد مريد مريد	ممام مبيمانين المسم	مسمع مامام امما		hu dua ala la via

Since the switch bracket for band mounting (made from nylon) are affected in an environment where alcohol, chloroform, methylamines, hydrochloric acid or sulfuric acid is splashed over, so it cannot be used. Please contact SMC regarding other chemicals.

*2 When mounting a D-M9DA(V) type auto switch, if the switch bracket is mounted on the indicator light, it may damage the auto switch. Therefore, be sure to avoid mounting the switch bracket on the indicator light.

*3 For band mounting, switch brackets are mounted on the cylinder when small switches are specified. (switches are not mounted, but packaged together). *4 For band mounting, when specifying the switches other than the small switches, auto switch(s) are mounted on the cylinder.

*5 For rail mounting, the auto switches and auto switch mounting brackets are packed together (not assembled).

*6 For rail mounting, when D-M9□A(V) is ordered separately, select the stainless steel mounting screw set BQ2-012S.

*7 When mounting a band and/or a rail on bore size ø8, ø10 or ø12 cylinder, D-A9□(V) type cannot be mounted.
 *8 When mounting a rail on bore size ø20 or ø25 cylinder, D-M9□(V), M9□W(V) and M9□A(V) types cannot be mounted.

Auto Switch Mounting Bracket/Single Unit Part Nos.

Auto switch				C75 Series							
model	ø 8	ø 10	ø 12	ø 32	ø 40						
	BJ2-008	BJ2-010	BJ2-012	BJ2-016	BM2-020A	BM2-025A	BM2-032A	BM2-040A			
	(A set of c, d, g)	(A set of c, d, g)	s set of c, d, g) (A set of c, d, g) (A set of c, d, g) (A set of c and d)								
D - M = D - M = D	BJ5-2		BJ5-1								
D-A3-(V)	(A set of a and b)		(A set of a and b)								
	BJ2-008S	BJ2-010S	BJ2-012S	BJ2-016S	BM2-020AS	BM2-025AS	BM2-032AS	BM2-040AS			
	(A set of c, f, g)	(A set of c, f, g)	(A set of c, f, g)	(A set of c, f, g)	(A set of c and f)						
	BJ4-2				BJ4-1						
	(A set of b and e)				(A set of b and e)	1					

[Stainless Steel Mounting Screw]

The following stainless steel mounting screw kit is available. Use it in accordance with the operating environment. (Since the auto switch mounting bracket is not included, order it separately.)

BBA4: For D-C7/C8/H7 types

Refer to the Web Catalog or Best Pneumatics for details on the BBA4.

When the D-H7BA type auto switch is shipped independently, the BBA4 is attached.

. _ _ _ _ _ _ г Other than the applicable auto switches listed in "How to Order", the following auto switches are mountable. L Refer to Best Pneumatics for the detailed specifications L Type Model Electrical entry Features Mounting Applicable bore size

			-		-		
2	Bood	D-C73, C76	Crommat (In line)	—	Bond	~9 to ~95	
ł	neeu	D-C80		Without indicator light	Danu	00 10 025	
i	Calid state	D-H7A1, H7A2, H7B	Crommet (In line)		Bond	a9 to a25	
i	Solid state	D-H7NW, H7PW, H7BW Grommet (In-line)		Diagnostic indication (2-color indicator)	Danu	00 10 025	

Normally closed (NC = b contact) solid state auto switches (D-M9 E(V)) are also available. For details, refer to Best Pneumatics. With pre-wired connector is also available for solid state switches. For details, refer to Best Pneumatics.



I

C85/C75 Series How to Mount and Move the Auto Switch

🗥 Caution

1. Tighten screws with the proper tightening torque.

2. Set the auto switch mounting band perpendicularly to cylinder tube.

Mounting Bracket Band Mounting Type

<Applicable auto switch>

Solid state --- D-M9N, M9P, M9B, M9NV, M9PV, M9BV

D-M9NŴ, M9PW, M9BW, M9NWÝ, M9PWV, M9BWV D-M9NA, M9PA, M9BA, M9NAV, M9PAV, M9BAV

Reed.....D-A90, A93, A96, A90V, A93V, A96V

■ How to Mount and Move the Auto Switch Mounting the Auto Switch

- Wrap the auto switch mounting band around the cylinder where the auto switch will be mounted without bending the reinforcing plates.
- 2. Connect the switch holder and switch bracket, and place them between the two ends of the auto switch mounting band (1).
- 3. Hook the bent part of the auto switch mounting band reinforcing plates onto the upper surface of the switch bracket. Bend the base of the auto switch mounting band reinforcing plates until the through holes of the switch bracket, the through holes of the auto switch mounting band, and the holes of the M3 female thread are aligned. Adjust the switch bracket so that both ends of the auto switch mounting band are inserted into the inner walls on both side surfaces of the switch bracket. For the D-M9□A(V) type auto switch, do not install the switch bracket on the indicator light.
- 4. Pass the auto switch mounting screw (M3) supplied with the auto switch mounting band from the through-hole side of the auto switch mounting band and engage it with the M3 female thread of the auto switch mounting band through the through-hole in the switch bracket.
- 5. Tighten the auto switch mounting screw with the specified tightening torque to secure the switch bracket and switch holder.

Tightening torque for auto switch mounting screw [N·m]

Culinder ceries	Bore size [mm]					
Cylinder series	ø8 to ø16	ø20 to ø40				
C85/C75	0.8 to 1.0	0.6 to 0.7				
6. Insert the auto switch into the auto switch mounting groove of the switch holder (2)						

- After checking the detection position, tighten the set screw (M2.5) supplied with the auto switch to secure the auto switch.
- At this time, the tightening torque for the set screw (M2.5) supplied with the auto switch must be 0.05 to 0.1 N·m.
- When tightening the set screw supplied with the auto switch, use a watchmaker's screw driver with a handle diameter of 5 to 6 mm. 8. Attach a protective cover to the tip of the auto switch mounting screw (M3).

Adjusting the Auto Switch Position

- To make the fine adjustment, loosen the set screw (M2.5) supplied with the auto switch and slide the auto switch inside the auto switch mouthing groove to adjust the position.
 To move the auto switch setting position largely, loosen the screw (M3)
- (2) To move the auto switch setting position largely, loosen the screw (M3) that secures the auto switch mounting band and slide the auto switch together with the switch holder on the cylinder tube to adjust the position.

< Applicable auto switch>

Solid state...D-H7A1, D-H7A2, D-H7B, D-H7BA D-H7C, D-H7NF, D-H7NW, D-H7PW, D-H7BW Reed......D-C73, D-C76, D-C80, D-C73C, D-C80C

How to Mount and Move the Auto Switch

- For ø16 or less: Put a mounting bracket on the cylinder tube. For ø20 or more: Wrap the auto switch mounting band around the cylinder where the auto switch will be mounted without bending the reinforcing plates.
- 2. For ø16 or less: Put the mounting section of the auto switch between the band mounting holes, then adjust the position of mounting holes of switch to those of mounting band.
 For ø20 or more: Hook the bent part of the auto switch mounting band reinforcing

For Ø20 or more: Hook the bent part of the auto switch mounting band reinforcing plates onto the upper surface of the switch. Bend the base of the auto switch mounting band reinforcing plates until the through holes of the switch bracket, the through holes of the auto switch mounting band, and the holes of the M3 female thread are aligned. Adjust the switch bracket so that both ends of the auto switch mounting band are inserted into the inner walls on both side surfaces of the switch bracket.
Lightly thread the auto switch mounting screw (M3) through the mounting

- 3. Lignity thread the auto switch mounting screw (M3) through the mounting hole into the thread part of band fitting. After scritter the whole bady to the determine position by sliding tighter the receiver.
- 4. After setting the whole body to the detecting position by sliding, tighten the mounting screw (M3) to secure the auto switch while properly contacting the auto switch bottom part and the cylinder tube. (The tightening torque of M3 screw should be as below.) ø8 to ø16: 0.8 to 1.0 N·m ø20 to ø40: 0.6 to 1.0 N·m
- ø20 to ø40: 0.6 to 1.0 N·m5. Modification of the detection position should be made in the condition of 3.6. After auto switch is mounted and fixed, attach a protective tube on the
- tip of an auto switch mounting screw (M3). (For ø8 to ø16)

[Stainless Steel Mounting Screw]

The following stainless steel mounting screw kit is available. Use it in accordance with the operating environment. (Since the auto switch mounting band is not included, order it separately.) BBA4: For D-C7/C8/H7 "D-H7BA" switch is set on the cylinder with the stainless steel screws above when shipped. When only an auto switch is shipped independently, the BBA4 is attached.

Stainless Steel Mounting Screw Set

Staniess Steel Mounting Serew Set						
Bort no	Contents		Applicable auto awitch mounting brocket part noo	Applicable		
Fait no.	Description	Quantity	Applicable auto switch mounting bracket part nos.	auto switch		
DDA4	Auto switch mounting scrow	4	BJ2-008S, BJ2-010S, BJ2-012S, BJ2-016S	D-C7, C8		
DDA4	Auto switch mounting screw		BM2-020AS, BM2-025AS, BM2-040AS	D-H7		

SMC



▲ Caution

Tighten the screw under the specified torque when mounting auto switch.
 Set the auto switch mounting band perpendicularly to cylinder tube.

For BM5

For BMA3



Auto Switch

Made to Order

Related Products

(With switch installed)

C85

C85W

C85-S/T

C85K

C85K-S/T

C85/C75 Series

Mounting Bracket Rail Mounting Type

<Applicable auto switch>

Solid state......D-M9N(V), D-M9P(V), D-M9B(V), D-M9NW(V), D-M9PW(V), D-M9BW(V), D-M9NA(V), D-M9PA(V), D-M9BA(V)

Reed......D-A90(V), A93(V), A96(V)

- 1. Slide the auto switch mounting nut inserted into the mounting rail and set it at the auto switch mounting position.
- Fit the convex part of the auto switch mounting bracket arm over the concave part of the rail, and slide the arm to the nut position.
 Push the auto switch mounting screw lightly into the hexagon nut
- 4. Remove the set screw (M2.5) attached to the auto switch.
- Insert the auto switch in the auto switch attachment part of the auto switch mounting bracket.
- 6. Secure the auto switch mounting screw (M2.5). (Tightening torque of M2.5 screw: 0.1 to 0.2 N·m)
- 7. Secure the auto switch mounting screw (3) (M3) after confirming the detecting position. (Tightening torque of M3 screw: 0.5 to 0.7 N·m)
- **8.** Modify the detecting position while the auto switch is secured at the position of (3) in the figure.



• BQ2-012 is a set of a and b shown above.



<Applicable auto switch>

Solid state......D-F79, D-F7P, D-J79, D-F7NV, D-F7PV, D-F7BV, D-J79C, D-F79W, D-F7PW, D-J79W, D-F7NWV, D-F7BWV, D-F79F, D-F7BA, D-F7BAV, Reed......D-A72, D-A73, D-A80, D-A72H, D-A73H, D-A76H, D-A80H, D-A73C, D-A80C, D-A79W

■ How to Mount and Move the Auto Switch

- 1. Slide the auto switch mounting nut (M3) inserted into the mounting rail and set it at the auto switch mounting position.
- 2. Fit the convex part of auto switch mounting arm into the concave part of auto switch mounting rail. Then slide the switch over the nut.
- 3. Push the auto switch mounting screw (M3) lightly into the mounting nut (M3) through the hole of auto switch mounting arm.
- After reconfirming the detecting position, tighten the mounting screw (M3) to secure the auto switch. (Tightening torque of M3 screw should be 0.5 to 0.7 N·m.)
- **5.** Modification of the detecting position should be made in the condition of 3.

[Stainless Steel Mounting Screw]

The following stainless steel mounting screw kit (including nuts) is available. Use it in accordance with the operating environment. (Since the auto switch spacer is not included, order it separately.)

BBA2: For D-A7/A8/F7/J7

"D-F7BA" auto switch is set on the cylinder with the stainless steel screws above when shipped.

When only an auto switch is shipped independently, the BBA2 is attached.

Stainless Steel Mounting Screw Set

Dort no	Contents				Applicable auto switch mounting	Appliable auto awitch
Fait no.	No.	Description	Size	Quantity	bracket part nos.	Applicable auto switch
		1 Auto switch mounting screw	M3 x 0.5 x 6 L	1	BMU1-025	
	1		M3 x 0.5 x 8 L	1	BQ-1	D-A7, A8
BBA2	2		M3 x 0.5 x 10 L	1	BQ-2	
	2	Auto switch mounting nut (Hexagon nut)	M3 x 0.5	1	BQ-1	D-F7, J7
	3	Auto switch mounting nut (Convex shape)	M3 x 0.5	1	BQ-2	

* A spacer for BQ-2 (black resin) is not included.

* When using D-A9□(V)/M9□(V)/M9□W(V)/M9□A(V) auto switches with BQ2-012, use stainless steel screws suitable for the auto switch mounting bracket.

117



Prior to Use Auto Switch Connections and Examples

Source Input Specifications

Sink Input Specifications



Connect according to the applicable PLC input specifications, as the connection method will vary depending on the PLC input specifications.

Examples of AND (Series) and OR (Parallel) Connections

* When using solid state auto switches, ensure the application is set up so the signals for the first 50 ms are invalid.

3-wire AND connection for NPN output

(Using relays)



3-wire AND connection for PNP output (Using relays)



2-wire AND connection



When two auto switches are connected in series, a load may malfunction because the load voltage will decline when in the ON state. The indicator lights will light up when both of the auto switches are in the ON state. Auto switches with a load voltage less than 20 V



Example: Power supply is 24 VDC Internal voltage drop in auto switch is 4 V.

(Performed with auto switches only)





2-wire OR connection

SMC





Example: Load impedance is 3 kQ. Leakage current from auto switch is 1 mA.

3-wire OR connection for NPN output



3-wire OR connection for PNP output



(Reed) Because there is no

current leakage, the load voltage will not increase when turned OFF However, depending on the number of auto switches in the ON state. the indicator lights may sometimes grow dim or not light up, due to the dispersion and reduction of the current flowing to the auto switches.

<u>ç</u> ð

Aut

C85/C75 Series Simple Specials/Made to Order

The following special specifications can be ordered as a simplified Made-to-Order. **Simple Specials** Please contact your local sales representative for more details.



Made to Order

		C85 (Standard)				C85K (Not-rotating rod)			
Symbol	Specifications	Double acting Single acting		Single acting	Double acting	Single acting			
		Sing	le rod	Doubl	e rod	Single rod	Single rod		
		Rubber	Air	Rubber	Air	Rubber	Rut	ober	
-XB6	Heat-resistant cylinder (-10 to 150°C)*2	•		•					
-XB7	Cold-resistant cylinder (-40 to 70°C)*3	•		•					
-XB9	Low speed cylinder (10 to 50 mm/s)*3	•							
-XC4	With heavy duty scraper*3	•		•					
-XC6□	Made of stainless steel	•	•	•	•	•	•	•	
	the all air quebien								

Excludes the ø8 air cushion

*2 Rubber bumper ø10 to ø40 only

*3 Rubber bumper ø20, ø25, ø32 and ø40 only
*4 For front mounting, only the ø20 and ø25 are available.

*5 For XB6, XB7 and XB9, only the ø20 and ø25 are available.

Simple Specials/Made to Order C85/C75 Series



C85/C75 Series Simple Specials

The following changes are dealt with through the Simple Specials System.

For details, refer to the Simple Specials in the Web Catalog. http://www.smcworld.com

Symbol -XA0 to XA30

1 Change of Rod End Shape Applicable Series

Series	Description	Model	Action	Note
		C85	Double acting, Single rod	Excludes the ø8 air cushion
	Standard	C85W	Double acting, Double rod	Excludes the ø8 air cushion
C 95		C85	Single acting (Spring return/extend)	
005	Non rotating rad	C85K	Double acting, Single rod	rod
	Non-rotating rou	C85K	Single acting (Spring return/extend)	
	Direct mount C85R Dou		Double acting, Single rod	For front mounting, only the ø20 and ø25 are available.
		C75	Double acting, Single rod	
	Standard	C75W	Double acting, Double rod	
075		C75	Single acting (Spring return/extend)	
075	Non rotating rad	C75K	Double acting, Single rod	
	Non-rotating rou	C75K	Single acting (Spring return/extend)	
	Direct mount	C75R	Double acting, Single rod	

Precautions

- 1. SMC will make appropriate arrangements if no dimension, tolerance, or finish instructions are given in the diagram.
- Standard dimensions marked with "*" will be as follows to the rod diameter (D). Enter any special dimension you require.
 D ≤ 6 → D−1 mm, 6 < D ≤ 25 → D−2 mm, D > 25 → D−4 mm
- 3. In the case of the double rod type and single acting retraction type, enter the dimensions when the rod is retracted.
- 4. "A0" is the same shape as the standard type. (The specifications of A0 are that only dimensions A and H are changed from the standard type.)



Simple Specials C85/C75 Series



122

C85/C75 Series Made to Order

Please contact SMC for detailed dimensions, specifications, and lead times.

1 Heat-resistant Cylinder (–10 to 150°C)



Air cylinder which changed the seal material and grease, so that it could be used even at higher temperature up to 150 from -10°C.

Applicable Series

Series	Description	Model	Action	Note
	Standard	C85	Double acting, Single rod	Rubber bumper ø10 to ø25 only Excludes with rod end (Accessory)
C85	Standard	C85W	Double acting, Double rod	Rubber bumper ø10 to ø25 only
	Direct mount	C85R	Double acting, Single rod	ø20, ø25 only Excludes with rod end (Accessory)
	Standard	C75	Double acting, Single rod	Rubber bumper only Excludes with rod end (Accessory)
C75	Stanuaru	C75W	Double acting, Double rod	Rubber bumper only
	Direct mount	C75R	Double acting, Single rod	Excludes with rod end (Accessory)

Operate without lubrication from a pneumatic system lubricator.
 Please contact SMC for details on the maintenance intervals for this cylinder, which differ from those of the standard cylinder.

* In principle, it is impossible to make built-in magnet type and the one with auto switch. But, as for the one with auto switch, and the heatresistant cylinder with heat-resistant auto switch, please contact SMC.

* Piston speed is ranged from 50 to 500 mm/s.

How to Order



Specifications

Ambient temperature range	-10°C to 150°C		
Seal material	Fluororubber		
Grease	Heat-resistant grease		
Auto switch	Not mountable*1		
Dimensions	Same as standard		
Specifications other than above	Same as standard		

*1 Manufacturing built-in magnet type and the one with auto switch is impossible.

▲Warning Precautions

Be aware that smoking cigarettes etc. after your hands have come into contact with the grease used in this cylinder can create a gas that is hazardous to humans.



2 Cold-resistant Cylinder (–40 to 70°C)

Air cylinder which changed the seal material and grease, so that it could be used even at lower temperature down to -40°C.

Applicable Series

Series	Description	Model	Action	Note
	Standard	C85	Double acting, Single rod	Rubber bumper ø20 and ø25 only Excludes with rod end (Accessory)
C85	Standard	C85W	Double acting, Double rod	Rubber bumper ø20 and ø25 only
	Direct mount C85R		Double acting, Single rod	ø20, ø25 only Excludes with rod end (Accessory)
	Standard	C75	Double acting, Single rod	Rubber bumper only Excludes with rod end (Accessory)
C75	Stanuaru	C75W	Double acting, Double rod	Rubber bumper only
	Direct mount	C75R	Double acting, Single rod	Excludes with rod end (Accessory)

Operate without lubrication from a pneumatic system lubricator.
 Use dry air which is suitable for heatless air dryer etc. not to cause the

Please contact SMC for details on the maintenance intervals for this

cylinder, which differ from those of the standard cylinder.

* Manufacturing built-in magnet type and mounting an auto switch are impossible.

* No cushion type is adopted. Piston speed is ranged from 50 to 500 mm/s.

How to Order



Specifications

Ambient temperature range	-40°C to 70°C		
Seal material	Low nitrile rubber		
Grease	Cold-resistant grease		
Auto switch	Not mountable*1		
Dimensions	Same as standard		
Specifications other than above	Same as standard		

*1 Manufacturing built-in magnet type and the one with auto switch is impossible.

∆Warning Precautions

Be aware that smoking cigarettes etc. after your hands have come into contact with the grease used in this cylinder can create a gas that is hazardous to humans.

3 Low Speed Cylinder (10 to 50 mm/s)

Even if driving at lower speeds 10 to 50 mm/s, there would be no stick-slip phenomenon and it can run smoothly.

Applicable Series

Series	Description	Model	Action	Note
C 95	Standard	C85	Double acting, Single rod	Rubber bumper ø20 and ø25 only
005	Direct mount	C85R	Double acting, Single rod	ø20, ø25 only
075	Standard	C75	Double acting, Single rod	Rubber bumper only
0/5	Direct mount	C75R	Double acting, Single rod	

How to Order



With Heavy Duty Scraper

It is suitable for using cylinders under the environment, where there are much dusts in a surrounding area by using a heavy duty scraper on the wiper ring, or using cylinders under earth and sand exposed to the die-casted equipment, construction machinery, or industrial vehicles.

Applicable Series

Series	Description	Model	Action	Note
C 95	Standard	C85	Double acting, Single rod	Rubber bumper ø20 to ø25 only
C05	Standard	C85W	Double acting, Double rod	Rubber bumper ø20 to ø25 only
C75	Standard	C75	Double acting, Single rod	Rubber bumper only

Specifications

Piston speed	10 to 50 mm/s		
Dimensions	Same as standard		
Specifications other than above	Same as standard		

* Operate without lubrication from a pneumatic system lubricator.

🗥 Warning Precautions

Be aware that smoking cigarettes etc. after your hands have come into contact with the grease used in this cylinder can create a gas that is hazardous to humans.

Symbol



Symbol

-XC6□

Symbol

-XB9

Heavy duty scraper

Specifications: Same as standard

▲ Caution

Either heavy duty scraper or rod seal cannot be replaced.

Construction (Dimensions are the same as standard.)

How to Order





Made of Stainless Steel 5

Suitable for the cases it is likely to generate rust by being immersed in the water and corrosion.

Applicable Series

Series	Description	Model	Action	Note
C85	Standard	C85	Double acting, Single rod	
		C85W	Double acting, Double rod	
		C85	Single acting (Spring return/extend)	
	Non-rotating rod	C85K	Double acting, Single rod	
		C85K	Single acting (Spring return/extend)	
	Direct mount	C85R	Double acting, Single rod	XC6A only
C75	Standard	C75	Double acting, Single rod	
		C75W	Double acting, Double rod	
		C75	Single acting (Spring return/extend)	
	Direct mount	C75R	Double acting, Single rod	XC6A only

How to Order



Specifications

Parts changed to stainless steel			Piston rod, Rod end nut					
Specifications other than above and external dimensions		Same as standard						
Description	Bore size [mm]							
Description	8	10	12	16	20	25		
Rod end nut	C85NT08A-S	C85NT08A-S	C85NT10A-S	C85NT10A-S	C85NT20A-S	C85NT25A-S		
Mounting nut	C85NT08B-S	C85NT08B-S	C85NT10B-S	C85NT10B-S	C85NT20B-S	C85NT20B-S		

Description	Bore size [mm]			
Description	32	40		
Rod end nut	C76NT32A-S	C76NT40A-S		
Mounting nut	C76NT32B-S	C76NT40B-S		

SMC

C85

C85W