# Circulating Fluid Temperature Controller Thermo-chiller









Inverter type

**Power consumption** 

1 kWh/h

**Facility water** 

**2** L/min

- Type of Fluorinated fluids/Ethylene glycol aqueous solution/ circulating fluid: Tap water, Deionized water
- Temperature range setting: -20 to 40°C/20 to 90°C/-20 to 90°C
- Cooling capacity: 1 kW/2 kW/4 kW/8 kW/10 kW to Max.15 kW
- Temperature stability: ±0.1 °C
- Refrigerant: R404A (HFC)/R134a (HFC)/R410A (HFC)/R448A (HFC/HFO)


# More effective energy-saving is achieved through use of a **DC inverter** compressor and an **inverter** pump.

|--|

HRS

HRS-R

# Energy Saving




**SMC** 


# Space Saving

Installation area: Max. 29% reduction (SMC comparison)

By emitting the heat from the rear side, ventilation slits on the side are unnecessary offering reduced installation space.


- Existing model: Body space: W400 mm x D845 mm Ventilation space: 100 mm
- HRZ008-H: Body space: W380 mm x D870 mm Ventilation space: 0





HRZ008-H 0.66 m<sup>2</sup>

Existing model 0.93 m<sup>2</sup>



# Communications

- Contact input/output signal
- Serial RS-485 communication
- Analog communication (Refer to "Options" on page 373.)
- DeviceNet communication (Refer to "Options" on

# DeviceNet

DeviceNet® is a registered trademark of ODVA, Inc.

# Fluid contact parts adopt the materials compatible for various circulating fluids.

(Stainless steel, EPDM, etc.)

• Fluorinated fluids: Flourinert™ FC-3283, FC-40

#### GALDEN<sup>®</sup> HT135. HT200

- 60% ethylene glycol aqueous solution
- Deionized water/Tap water


Regarding the fluid other than the above, please contact SMC. Flourinert<sup>™</sup> is a trademark of 3M. GALDEN<sup>®</sup> is a registered trademark of Solvay Solexis, Inc.


# Easy Maintenance

Circulating fluid automatic recovery function (Refer to "Options" on page 374.)

Circulating fluid inside a thermo-chiller tank can be recovered automatically. (Recovery volume: 15 L to 17 L)

- Reduced maintenance time
- Faster operation
- Reduced circulating liquid loss by evaporation or spill





# Circulating fluid electric

resistance ratio control function (Refer to "Options" on page 373.) (DI control kit)


## Easy maintenance

Checking the electrical component parts accessible from the front side only




- Possible to replace the maintenance parts (such as a pump) without removing the pipings and discharging the circulating fluid.
- Various alarm displays (Refer to page 369.)

SMC



# **Application Examples**



HRS

HRS-R

HRSH090 HRS200

HRSH

HRSE

HRR

HRL

HRZ

HRZD

HRW


HECR

HEC

HEB

HED





#### Circulating fluid circuit

With the **circulating pump**, circulating fluid will be discharged to the user's equipment side. After the circulating fluid will heat or cool the user's equipment side, it will be returned to the **main tank** via the **heat exchanger**.

A **sub-tank** is not used under the normal operation. It will be used when a circulating fluid is recovered from the user's equipment side.

The **internal pump** is used to transfer a circulating fluid from the **sub-tank** to the **main tank**. (Refer to "Circulating fluid automatic recovery function" on page 347.)

#### **Refrigeration circuit**

When the circulating fluid temperature is rising higher than the set temperature, open the **expansion valve (a)** to introduce refrigerant gas at a lower temperature to the **heat exchanger**. With this, the circulating fluid will be cooled down.

Oppositely, when the circulating fluid is getting lower against the set temperature, open the **expansion valve (b)** and introduce refrigerant gas at a high temperature without going through the **water-cooled condenser** to the **heat exchanger**. With this heat, the circulating fluid will be heated.

# CONTENTS HRZ Series

# 

# Thermo-chiller HRZ Series

### Model Selection

Guide to Model Selection Page 3	51
Required Cooling Capacity Calculation Page 3	52
Precautions on Model Selection Page 3	53
Circulating Fluid Typical Physical Property Values ··· Page 3	54

### Fluorinated Fluid Type

How to Order/Specifications F	age 355
Cooling Capacity/Heating Capacity F	age 356
Pump Capacity F	age 357

### Ethylene Glycol Type

How to Order/Specifications P	'age 358
Cooling Capacity/Heating Capacity P	'age 359
Pump Capacity ·····P	age 360

### Tap/Deionized Water Type

How to Order/Specifications	Page 361
Cooling Capacity/Heating Capacity/Pump Capacity ···	Page 362

### Double Inverter Type

How to Order/Specifications	Page 363	3
Cooling Capacity/Heating Capacity/Pump Capacity ···	Page 364	ŀ

### Common Specifications

•		
Dimensions	Page	365
Communication Functions	Page	367
Contact Input/Output	Page	367
· Serial RS-485 ·····	Page	368
· Connector Location	Page	368
Operation Display Panel	Page	369
Alarm	Page	369

### Optional Accessories

①Bypass Piping Set ······	Page	370
2 Anti-quake Bracket ······	Page	370
34-Port Manifold ·····	Page	371
④ DI Filter ······	Page	371
(5) Insulating Material for DI Filter	Page	371
6 60% Ethylene Glycol Aqueous Solution	Page	372
⑦ Concentration Meter ······	Page	372

### Options

Analog Communication	Page 373
DeviceNet Communication	Page 373
NPT Fitting	Page 373
SI Unit Only	Page 373
DI Control Kit ·····	Page 373
Circulating Fluid Automatic Recovery	Page 374
EU F-Gas Regulation-compliant	Page 375

Specific Product Precautions Page 378



HRS

**SMC** 



### Guide to Model Selection

#### 1. How much is the temperature in degrees centigrade for the circulating fluid?

#### Temperature range which can be set with the thermo-chiller

L : -20°C to 40°C ("L2" (tap water, deionized water specification) can be set 10°C to 40°C.)

H : 20°C to 90°C


W: -20°C to 90°C (Select "W" only when the temperature ranges of "L" or "H" are not applicable. HRZ010-W2S (tap water, deionized water specification) can be set 10°C to 60°C.)

Example) User requirement: 50°C (→ Temperature range 20°C to 90°C, "H" type will be appropriate.)

#### 2. What kind of the circulating fluids will be used?

#### Relationship between circulating fluid (which can be used with the thermo-chiller) and temperature

Fluorinated fluids: Fluorinert<sup>™</sup> FC-3283/GALDEN<sup>®</sup> HT135



Example) User requirement: Fluorinated fluids


Based on the results 1. and 2., Cooling capacity relating "Fluorinated fluids" and "Temperature range  $20^{\circ}$ C to  $90^{\circ}$ C" is shown on page 356.

# 3. What is the kW for the required cooling capacity? \* To calculate the cooling capacity, referring to page 352.

Example) User requirement: 5 kW  $\rightarrow$ 

Plot the point of intersection between the operating temperature (50°C) and the cooling capacity (5 kW) in the cooling capacity graph.

#### [Cooling Capacity Graph] Circulating Fluid: Fluorinated Fluids, Temperature Range: 20 to 90°C



The point plotted in the graph is the requirement from the user. Select the thermo-chiller models exceeding this point. In this case, select the **HRZ004-H**.

GALDEN® is a registered trademark, belonging to the Solvay Group or its corresponding owner. Fluorinert™ is a trademark of 3M.

### Example 1: When the heat generation amount in the user's equipment is known.

#### Heat generation amount Q: 3.5 kW

Cooling capacity = Considering a safety factor of 20%, **3.5 x 1.2 = 4.2 kW** 

Specific heat C:

. 0.96 x 10³ J/(kg⋅K)

#### Example 2: When the heat generation amount in the user's equipment is not known.

# Obtain the temperature difference between inlet and outlet by circulating the circulating fluid inside the user's equipment.

Heat generation amount Q: UnknownCirculating fluid temperature difference  $\Delta T (= T2 - T1)$ : 6.0°C (6.0 K)Circulating fluid outlet temperature T1: 20°C (293.15 K)Circulating fluid return temperature T2: 26°C (299.15 K)Circulating fluid flow rate L: 20 L/minCirculating fluid: Fluorinated fluid<br/>Density  $\gamma$ : 1.80 x 103 kg/m3

 (at 20°C)
 Refer to page 354 for the typical physical property values by circulating fluid.


$$\mathbf{Q} = \frac{\Delta \mathbf{T} \mathbf{x} \mathbf{L} \mathbf{x} \,\gamma \, \mathbf{x} \, \mathbf{C}}{\mathbf{60} \, \mathbf{x} \, \mathbf{1000}}$$

 $=\frac{6.0 \times 20 \times 1.80 \times 10^3 \times 0.96 \times 10^3}{60 \times 1000}$ 

= 3456 W = 3.5 kW

Cooling capacity = Considering a safety factor of 20%,  $3.5 \times 1.2 = 4.2 \text{ kW}$ 

Thermo-chiller



#### Unknown $6.0^{\circ}C$ $20^{\circ}C$ $26^{\circ}C$ $1.2 \text{ m}^3/\text{h}$ Fluorinated fluid Density $\gamma$ : $1.80 \times 10^3 \text{ kg/m}^3$ Specific heat **C**: $0.23 \text{ kcal/kg} \cdot ^{\circ}C$ (at $20^{\circ}C$ )

Example of conventional units (Reference)

 Refer to page 354 for the typical physical property values by circulating fluid.

$$\mathbf{Q} = \frac{\Delta \mathbf{T} \mathbf{x} \mathbf{L} \mathbf{x} \, \gamma \, \mathbf{x} \, \mathbf{C}}{\mathbf{860}}$$

$$=\frac{\frac{6.0 \times 1.2 \times 1.80 \times 10^3 \times 0.23}{860}}$$

Cooling capacity = Considering a safety factor of 20%,

3.5 x 1.2 = 4.2 kW

# HRZ Series

## **Required Cooling Capacity Calculation**

# Example 3. When there is no heat generation, and when cooling the object below a certain temperature and period of time.

Cooled substance total volume V : 60 L	Example
Cooling time h : 15 min	0.06 m <sup>3</sup>
Cooling temperature difference $\Delta T$ : 20°C (20 K)	0.25 h
$\left\{(40^{\circ}\text{C}-20^{\circ}\text{C}\rightarrow20^{\circ}\text{C})\right.$	20°C
Circulating fluid : Fluorinated fluid	Fluorinat
Density γ: 1.80 x 10 <sup>3</sup> kg/m <sup>3</sup>	Density 2
Specific heat <b>C</b> : 0.96 x 10 <sup>3</sup> J/(kg·K) (at 20°C)	Specific
<ul> <li>Refer to page 354 for the typical physical property values by circulating fluid.</li> </ul>	* Refer by circ
$\mathbf{Q} = \frac{\Delta \mathbf{T} \mathbf{x} \mathbf{V} \mathbf{x} \ \gamma \mathbf{x} \mathbf{C}}{\mathbf{h} \mathbf{x} 60 \mathbf{x} 1000}$	$Q = \frac{\Delta T}{\Delta T}$
20 x 60 x 1.80 x 10 <sup>3</sup> x 0.96 x 10 <sup>3</sup>	20

<u>15 x 60 x 1000</u>


= 2304 W = 2.3 kW

Cooling capacity = Considering a safety factor of 20%,

# 2.3 x 1.2 = 2.8 kW (When the circulating fluid temperature is 20°C.)

(In this case, selected thermo-chiller model will be either HRZ002-L or HRZ004-H.)

Thermo-chiller



\* This is the calculated value by changing the fluid temperature only. Thus, it varies substantially depending on the water bath or piping material or shape.

### **Precautions on Model Selection**

#### 1. Heating capacity

When setting the circulating fluid temperature at a higher temperature than the room temperature, the circulating fluid temperature will be heated with the thermo-chiller. Heating capacity varies depending on the model of the HRZ series. Also, the heating capacity varies depending on the circulating fluid temperature. Consider the heat radiation amount or thermal capacity of the user's equipment. Check beforehand if the required heating capacity is provided, based on the heating capacity graph for the respective model.

#### 2. Pump capacity

#### <Circulating fluid flow rate>

Pump capacity varies depending on the model selected from the HRZ series. Also, circulating fluid flow varies depending on the circulating fluid discharge pressure. Consider the installation height difference between our thermo-chiller and a user's equipment, and the piping resistance such as circulating fluid pipings, or piping size, or piping curves in the machine. Check beforehand if the required flow is achieved using the pump capacity curves for each respective model.

#### <Circulating fluid discharge pressure>

Circulating fluid discharge pressure has the possibility to increase up to the maximum pressure in the pump capacity curves for the respective model. Check beforehand if the circulating fluid pipings or circulating fluid circuit of the user's equipment are fully durable against this pressure.

le of conventional units (Reference) ated fluid γ: 1.80 x 10<sup>3</sup> kg/m<sup>3</sup> heat C: 0.23 kcal/kg·°C (at 20°C) to page 354 for the typical physical property values culating fluid. ΤΧVΧΥΧΟ h x 860 20 x 0.06 x 1.80 x 10<sup>3</sup> x 0.23 0.25 x 860 = 2.3 kW Cooling capacity = Considering a safety factor of 20%,  $2.3 \times 1.2 = 2.8 \text{ kW}$  (When the circulating fluid temperature is 20°C.) (In this case, selected thermo-chiller model will be either HRZ002-L or HRZ004-H.)



# Model Selection HRZ Series

### **Circulating Fluid Typical Physical Property Values**

\* Shown below are reference values. Please contact circulating fluid supplier for details.

#### **Fluorinated Fluids**

Physical property	Density $\gamma$	Specific heat C	
value	[kg/m <sup>3</sup> ] [g/L]	[J/(kg·K)]	([kcal/kg⋅°C])
Temperature		[0/(kg·k)]	
–10°C	1.87 x 10 <sup>3</sup>	0.87 x 10 <sup>3</sup>	(0.21)
20°C	1.80 x 10 <sup>3</sup>	0.96 x 10 <sup>3</sup>	(0.23)
50°C	1.74 x 10 <sup>3</sup>	1.05 x 10 <sup>3</sup>	(0.25)
80°C	1.67 x 10 <sup>3</sup>	1.14 x 10 <sup>3</sup>	(0.27)

#### 60% Ethylene Glycol Aqueous Solution

Physical property value	Density $\gamma$	Specific heat C	
Temperature	[kg/m³] [g/L]	[J/(kg·K)]	([kcal/kg⋅°C])
–10°C	1.10 x 10 <sup>3</sup>	3.02 x 10 <sup>3</sup>	(0.72)
20°C	1.08 x 10 <sup>3</sup>	3.15 x 10 <sup>3</sup>	(0.75)
50°C	1.06 x 10 <sup>3</sup>	3.27 x 10 <sup>3</sup>	(0.78)
80°C	1.04 x 10 <sup>3</sup>	3.40 x 10 <sup>3</sup>	(0.81)

#### Water

Density  $\gamma$ : 1 x 10<sup>3</sup> [kg/m<sup>3</sup>] [g/L]

Specific heat C: 4.2 x 10<sup>3</sup> [J/(kg·K)] (1.0 [kcal/kg·°C])

# Thermo-chiller Fluorinated Fluid Type


# HRZ Series

How to Order

The models on this page are to be discontinued as of December 2022. Therefore, we recommend considering an HRZ-F series model instead. For further details on the HRZ-F series, refer here.

CE

SEMI



 When multiple options are combined, indicate symbols in alphabetical order.

Specifications (For details, please refer to our "Product Specifications" information.)

	Model	HRZ001-L	HRZ002-L	HRZ001-H	HRZ002-H	HRZ004-H	HRZ008-H	HRZ002-W	HRZ008-W	
Coc	oling method			·	Water-cooled	refrigeration				
Ref	rigerant	R404A (HFC)								
Ref	rigerant charge kg	1.15	1.15	0.75	0.75	1.15	1.15	1.15	1.15	
Con	itrol system				PID c	ontrol				
Am	bient temp./humidity*1			Tempera	ture: 10 to 35°C	, Humidity: 30 to	o 70%RH			
	Circulating fluid*2	Fluorinert <sup>™</sup> GALDEN		Flu	Fluorinert <sup>™</sup> FC-40/GALDEN <sup>®</sup> HT200 FC-328 • 20 to 90			FC-3283/GA • 20 to 90°C: I	°C: Fluorinert™ GALDEN <sup>®</sup> HT135 C: Fluorinert™ ALDEN <sup>®</sup> HT200	
<u>e</u>   1	Femp. range setting <sup>∗1</sup> °C	-20	to 40		20 t	o 90		-20	to 90	
0	Cooling capacity <sup>*3</sup> kW	1.0 (at –10°C)	2.0 (at –10°C)	1.0 (at 20°C)	2.0 (at 20°C)	4.0 (at 20°C)	8.0 (at 20°C)	2.0 (at 20°C)	8.0 (at 20°C)	
	Heating capacity*3 kW	2.8 (at –10°C)	3.2 (at –10°C)	2.3 (at 20°C)	2.6 (at 20°C)	2.8 (at 20°C)	3.0 (at 20°C)	2.3 (at 20°C)	3.3 (at 20°C)	
l in l	Γemp. stability <sup>*4</sup> °C				±C	).1				
	Pump capacity 50/60 Hz)*5 MPa	0.45/0.65 (a	at 20 L/min)		/0.60 L/min)		0.45/0.65 (	at 20 L/min)		
เอิโ	Rated flow <sup>*6</sup> L/min	2	0			2	0			
	Main tank capacity*7 L	Appro	ox. 15	Appro	ox. 12		Appr	prox. 15		
	Sub-tank capacity <sup>*8</sup> L	Appro	ox. 16	Appro	ox. 15	Approx. 16				
	Port size				Rc	3/4				
	Fluid contact material		Stainless s	teel, EPDM, Co			PPS, Silicone,	Fluororesin		
≒ ⊢	Femperature range °C				10 t	o 25				
l sk	Pressure range MPa				0.3 t			1		
	Required flow rate (50/60 Hz)*9 L/min	5/5	6/6	3/4	5/6	9/10	13/14	6/7	13/14	
	Port size			Rc1/2						
	Fluid contact material			s steel, EPDM, (		· · ·				
	Power supply			VAC 50 Hz, 3-p		8 VAC 60 Hz A	v	U		
s	Breaker capacity A		0	20		30				
O		A 20 14				2	23			
l ect	Alarm				Refer to p	<u> </u>				
	Communications			· ·	,	5-485 (D-sub 9 p	7 1	ages 367 and 36	8.)	
	ght <sup>*10</sup> kg	16	55	· ·	45			65		
L	ety standards*11			UL, CE markir	ig, SEMI (S2, S	8, F47), SEMA1	IECH (S2, S8)			

\*1 No condensation should be present.

\*2 GALDEN<sup>®</sup> is a registered trademark, belonging to the Solvay Group or its corresponding owner. Fluorinert™ is a trademark of 3M. Regarding the fluid other than the above, please contact SMC.

\*3 ① Facility water temperature: 25°C, ② Circulating fluid flow rate: Values at the rated circulating fluid flow rate. Values common for 50/60 Hz.

\*4 Value with a stable load without turbulence in the operating conditions. It may be out of this range depending on operating conditions.

\*5 The capacity at the thermo-chiller outlet when the circulating fluid temperature is 20°C

\*6 The required flow rate for maintaining the cooling capacity or temperature stability. When used below the rated flow, use the individually sold, "Bypass Piping Set" (Refer to page 370).

\*7 Minimum volume required for operating only the thermo-chiller. (Circulating fluid temperature: 20°C, including the thermo-chiller's internal pipings or heat exchanger)

\*8 Preliminary space volume without main tank capacity. Available for collecting the circulating fluid inside an external piping or for preliminary injection.


\*9 The required flow rate when the cooling capacity load is applied at a facility water temperature of 25°C

\*10 Weight in the dry state without circulating fluids


\*11 The import of products using R404A as a refrigerant, even if they have a CE mark, into the EU is prohibited.



## **Cooling Capacity**




### HRZ002-W/008-W




# **Heating Capacity**


### HRZ001-L/002-L




#### HRZ002-W/008-W



### HRZ001-H/002-H/004-H/008-H



# HRZ001-H/002-H/004-H/008-H






356 @ INFORMATION cat43 2024-05




# HRZ Series

## Pump Capacity (Thermo-chiller Outlet)

### HRZ001-L/002-L




### HRZ004-H/008-H HRZ002-W/008-W



 When the circulating fluid flow is below 6 L/min, the in-built operation stop alarm will be activated. It is not possible to run the equipment. (common for all models)

### HRZ001-H/002-H



# Thermo-chiller Ethylene Glycol Type

# HRZ Series

#### How to Order

The models on this page are to be discontinued as of December 2022. Therefore, we recommend considering an HRZ-F series model instead. For further details on the HRZ-F series, refer here.

CE

SEMI

HRS

HRS 100/150 HRS090 HRS-R

HRS200

HRSH090

HRSH

HRSE

HRR

HRL

HRZ

HRZD

HRW


HECR

HEC

HEB

HED

Technical Data



Ethylene glycol type

#### Specifications (For details, please refer to our "Product Specifications" information.)

	Model			HRZ001-H1	HD7002-H1			HRZ002-W1	HD7009-W1
<u> </u>	poling method					d refrigeration			
	efrigerant	R404A (HFC)							
	efrigerant charge kg	1.15	1.15	0.75	0.75	1.15	1.15	1.15	1.15
	ontrol system	1.15	1.15	0.75	••	ontrol	1.15	1.15	1.15
	nbient temp./humidity*1			Tomporo		, Humidity: 30 t			
	Circulating fluid*2					ol aqueous solu			
	Temp. range setting <sup>*1</sup> °C	_20	to 40	007		0 90		_20	to 90
	Temp. range setting 0	1.0	2.0	1.0	2.0	4.0	8.0	2.0	8.0
system	Cooling capacity*3 kW	(at –10°C)	(at –10°C)	(at 20°C)	(at 20°C)	(at 20°C)	(at 20°C)	(at 20°C)	(at 20°C)
d sys	Heating capacity*3 kW	2.5 (at –10°C)	2.9 (at –10°C)	1.8 (at 20°C)	2.1 (at 20°C)	2.5 (at 20°C)	3.0 (at 20°C)	2.2 (at 20°C)	3.3 (at 20°C)
fluid	Temp. stability <sup>*4</sup> °C	(		(	±(	).1	(	(	(
Circulating f	Pump capacity (50/60 Hz)*5 MPa	0.25/0.40 (	at 20 L/min)	0.25/0.35 (a		0.25/0.40 (at 20 L/min)			
ula	Rated flow <sup>*6</sup> L/min				2	20			
i,	Main tank capacity <sup>*7</sup> L	Appro	ox. 15	Appro	ox. 12	Approx. 15			
0	Sub-tank capacity*8 L	Appro	ox. 16	Appro	ox. 15	Approx. 16			
	Port size				Ro	3/4			
	Fluid contact material		Stainless s	teel, EPDM, Co	pper brazing (H	eat exchanger)	, PPS, Silicone,	Fluororesin	
tem	Temperature range °C				10 t	o 25			
r sys	Pressure range MPa				0.3 t	o 0.7			
wate	Required flow rate (50/60 Hz)*9 L/min	5/5	6/6	3/4	5/6	9/10	13/14	5/7	13/14
Cooling water system	Port size				Ro	:1/2			
ð	Fluid contact material			s steel, EPDM, 0		· ·			
em	Power supply	3-phase 200 VAC 50 Hz, 3-phase 200 to 208 VAC 60 Hz Allowable voltage range $\pm 10\%$				e range ±10%			
syst	Breaker capacity A	3	0	20		30			
Electrical system	Rated current A	1	9	14			2	23	
ectri	Alarm		Refer to page 369.						
_	Communications			out (D-sub 25 pir	,	6-485 (D-sub 9		•	68.)
	eight <sup>*10</sup> kg	10	65		15			65	
Sa	fety standards*11			UL, CE markir	ng, SEMI (S2, S	8, F47), SEMA	TECH (S2, S8)		

\*1 No condensation should be present.

\*2 Dilute pure ethylene glycol with tap water. Additives such as preservatives cannot be used.

\*3 ① Facility water temperature: 25°C, ② Circulating fluid flow rate: Values at the rated circulating fluid flow rate. Values common for 50/60 Hz.

\*4 Value with a stable load without turbulence in the operating conditions. It may be out of this range when a DI control kit (option Y) is used or in some other operating conditions.

\*5 The capacity at the thermo-chiller outlet when the circulating temperature is 20°C

\*6 The required flow rate for maintaining the cooling capacity or temperature stability. When used below the rated flow, use the individually sold, "Bypass Piping Set" (Refer to page 370).

\*7 Minimum volume required for operating only the thermo-chiller. (Circulating fluid temperature: 20°C, including the thermo-chiller's internal pipings or heat exchanger)

\*8 Preliminary space volume without main tank capacity. Available for collecting the circulating fluid inside an external piping or for preliminary injection.


\*9 The required flow rate when the cooling capacity load is applied at a facility water temperature of 25°C

\*10 Weight in the dry state without circulating fluids


\*11 The import of products using R404A as a refrigerant, even if they have a CE mark, into the EU is prohibited.

# HRZ Series

## **Cooling Capacity**




### HRZ002-W1/008-W1




# **Heating Capacity**


### HRZ001-L1/002-L1



#### HRZ002-W1/008-W1



### HRZ001-H1/002-H1/004-H1/008-H1




#### HRZ001-H1/002-H1/004-H1/008-H1 4 Heating capacity [kW] HRZ008-H1 3 HRZ004-H1 HRZ002-H1 2 HRZ001-H1 1 0 20 30 70 80 90 40 50 60 Circulating fluid temperature [°C]




### Pump Capacity (Thermo-chiller Outlet)

### HRZ001-L1/002-L1 HRZ004-H1/008-H1 HRZ002-W1/008-W1



# HRZ001-H1/002-H1



\* When the circulating fluid flow is below 6 L/min, the in-built operation stop alarm will be activated. It is not possible to run the equipment. (common for all models)




# Thermo-chiller Tap/Deionized Water Type

# HRZ Series

How to Order

The models on this page are to be discontinued as of December 2022. Therefore, we recommend considering an HRZ-F series model instead. For further details on the HRZ-F series, refer here.

CE



#### Specifications (For details, please refer to our "Product Specifications" information.)

Model		HRZ001-L2	HRZ002-L2	HRZ004-L2	HRZ008-L2		
Cooling method		Water-cooled refrigeration					
Refrigerant		R134a (HFC)					
Refrigerant charge	kg	1.1	1.1	1.1	1.1		
Control system			PID co	ntrol			
Ambient temperature/humidity*	1		Temperature: 10 to 35°C,	Humidity: 30 to 70%RH			
Circulating fluid*2			Tap water, Dei	onized water			
Temperature range setting*1	°C		10 to	40			
Cooling capacity*3	kW	1.0 (at 20°C)	2.0 (at 20°C)	4.0 (at 20°C)	8.0 (at 20°C)		
Heating capacity*3	kW	0.90 (at 20°C)	0.98 (at 20°C)	1.15 (at 20°C)	1.25 (at 20°C)		
Heating capacity*3 Temperature stability*4	ability*4 °C ±0.1						
Pump capacity (50/60 Hz)*5	MPa	Pa 0.25/0.38 (at 20 L/min)					
Pump capacity (50/60 Hz)*5 Rated flow*6 Main tank capacity*7 Sub-tank capacity*8	L/min		20				
Main tank capacity*7	L		Approx	ĸ. 15			
Sub-tank capacity <sup>*8</sup>	L		Approx	ĸ. 16			
Port size			Rc3	/4			
Fluid contact material		Stainless stee	I, EPDM, Copper brazing (He	at exchanger), PPS, Silicor	ne, Fluororesin		
Temperature range	°C		10 to	25			
Temperature range         Pressure range         Required flow rate (50/60 Hz)*9	MPa		0.3 to	-			
Required flow rate (50/60 Hz)*9	<sup>9</sup> L/min	5/5	6/6	15/22	18/23		
Port size Fluid contact material			Rc1	/=			
			eel, EPDM, Copper brazing (	<b>Q</b> /: .			
Breaker capacity		3-phase 200 VAC 50 Hz, 3-phase 200 to 208 VAC 60 Hz $$ Allowable voltage range $\pm 10\%$					
Breaker capacity	Α	30					
Rated current	Α	19					
Rated current		Refer to page 369.					
					pages 367 and 368.)		
Weight <sup>*10</sup>	kg		16				
Safety standards		U	L, CE marking, SEMI (S2, S8	, F47), SEMATECH (S2, S	8)		

\*1 No condensation should be present.

\*2 If tap water or deionized water is used, use water that is compliant with the Water Quality Standards of the Japan Refrigeration and Air Conditioning Industry Association (JRA GL-02-1994/cooling water system - circulation type - make-up water). The minimum electric conductivity of the deionized water used as the fluid should be 0.5 µS/cm (or electric resistivity 2 MΩ•cm at maximum).

\*3 ① Facility water temperature: 25°C, ② Circulating fluid flow rate: Values at the rated circulating fluid flow rate. Values common for 50/60 Hz.

\*4 Value with a stable load without turbulence in the operating conditions. It may be out of this range when a DI control kit (option Y) is used or in some other operating conditions. \*5 The capacity at the thermo-chiller outlet when the circulating fluid temperature is 20°C

\*6 The required flow rate for maintaining the cooling capacity or temperature stability. When used below the rated flow, use the individually sold, "Bypass Piping Set" (Refer to page 370).
\*7 Minimum volume required for operating only the thermo-chiller. (Circulating fluid temperature: 20°C, including the thermo-chiller's internal pipings or heat exchanger)

\*8 Preliminary space volume without main tank capacity. Available for collecting the circulating fluid inside an external piping or for preliminary injection.


\*9 The required flow rate when the cooling capacity load is applied at a facility water temperature of 25°C

\*10 Weight in the dry state without circulating fluids




### **Cooling Capacity**

### HRZ001-L2/002-L2/004-L2/008-L2



## Pump Capacity (Thermo-chiller Outlet)


### HRZ001-L2/002-L2/004-L2/008-L2




 When the circulating fluid flow is below 6 L/min, the in-built operation stop alarm will be activated. It is not possible to run the equipment. (common for all models)

# Heating Capacity

### HRZ001-L2/002-L2/004-L2/008-L2








# Thermo-chiller Double Inverter Type

# HRZ Series

#### How to Order

The models on this page are to be discontinued as of December 2022. Therefore, we recommend considering an HRZ-F series model instead. For further details on the HRZ-F series, refer here.

( (



#### Double inverter type

	Model		HRZ010-WS	HRZ010-W1S	HRZ010-W2S			
С	ooling method		Water-cooled refrigeration					
R	efrigerant			R404A (HFC)				
Refrigerant charge kg			1.55	1.55	1.55			
	ontrol system		PID control					
Α	mbient temperature/humidity*	1	Tempe	erature: 10 to 35°C, Humidity: 30 to 7	0%RH			
	Circulating fluid*2		<ul> <li>–20 to 40°C: Fluorinert<sup>™</sup></li> <li>FC-3283/GALDEN<sup>®</sup> HT135</li> <li>20 to 90°C: Fluorinert<sup>™</sup></li> <li>FC-40/GALDEN<sup>®</sup> HT200</li> </ul>	60% ethylene glycol aqueous solution	Tap water, Deionized water			
E	Temperature range setting*1	°C	-20		10 to 60			
system	Cooling capacity <sup>*3</sup>	kW	10 (at 20°C)	10 (at 20°C)	9 (at 20°C)			
fluid	Heating capacity*3	kW	5.0 (at 20°C)	4.5 (at 20°C)	2.5 (at 20°C)			
ing	Temperature stability*4	°C	±0.1 (In cases when the circulating fluid discharge port and the return port are directly connected)					
Circulating	Pump capacity <sup>*5</sup>	MPa	Max. 0.72 (at 20 L/min)	Max. 0.40 (at 20 L/min)	Max. 0.38 (at 20 L/min)			
2	Rated flow <sup>*6</sup>	L/min		20				
Ö	Flow range <sup>*7</sup>	L/min	10 to 40 (With flow control function by inverter)					
	Main tank capacity <sup>*8</sup>	L	Approx. 15					
	Sub-tank capacity <sup>*9</sup>	L	Approx. 16					
	Port size		Rc3/4					
	Fluid contact material		Stainless steel, EPDM, Copper brazing (Heat exchanger), PPS, Silicone, Fluororesin					
tem	Temperature range	°C	10 t	o 30	10 to 25			
Cooling water system	Pressure range	MPa		0.3 to 0.7				
wate	Required flow rate (50/60 Hz)*10	<sup>)</sup> L/min		15/15				
oling	Port size		Rc1/2					
	Fluid contact material		Stainless steel, EPDM, Copper brazing (Heat exchanger), PPS, Silicone, Brass, NBR					
tem	Power supply		3-phase 200 VAC 50 Hz, 3-phase 200 to 208 VAC 60 Hz Allowable voltage range ±10%					
system	Breaker capacity	A						
cal	Rated current	Α	26	25	25			
Electrical	Alarm		Refer to page 369.					
	Communications		Contact input/output (D-sub 25	pin) and Serial RS-485 (D-sub 25 pin	) (Refer to pages 367 and 368.)			
	eight*11	kg		165				
	afety standards*12		UL, CE ma	rking, SEMI (S2, S8, F47), SEMATEC	CH (S2, S8)			
×1	No condensation should be present.							

ensation should be present

Specifications

\*2 GALDEN<sup>®</sup> is a registered trademark, belonging to the Solvay Group or its corresponding owner. Fluorinert™ is a trademark of 3M. Dilute pure ethylene glycol with tap water. Additives such as preservatives cannot be used. If tap water or deionized water is used, use water that is compliant with the Water Quality Standards of the Japan Refrigeration and Air Conditioning Industry Association (JRA GL-02-1994/cooling water system - circulation type - make-up water). The minimum electric conductivity of the deionized water used as the fluid should be 0.5 μS/cm (or electric resistivity 2 MΩ•cm at maximum). \*3 ① Facility water temperature: 25°C, ② Circulating fluid flow rate: Values at the rated circulating fluid flow rate. Values common for 50/60 Hz.

Value with a stable load without turbulence in the operating conditions. It may be out of this range when a DI control kit (option Y) is used or in some other operating conditions.

\*\* Value with a stable load without inductive in the operating conductors. It may be out of in an get with a Dr control with (option 1) is used of in some other operating conductors.
\*5 The capacity at the thermo-chiller outlet when the circulating fluid temperature is 20°C
\*6 The required flow rate for maintaining the cooling capacity or temperature stability. When used below the rated flow, use the individually sold, "Bypass Piping Set" (Refer to page 370).
\*7 May not be able to control with the set value depending on the piping specification in the user side.
\*8 Minimum volume required for operating only the thermo-chiller. (Circulating fluid temperature: 20°C, including the thermo-chiller's internal pipings or heat exchanger)
\*9 Preliminary space volume without main tank capacity. Available for collecting the circulating fluid inside an external piping or for preliminary injection.
\*10 The capacity at the new indice and the provided stability water temperature is 20°C.


\*10 The required flow rate when the cooling capacity load is applied at a facility water temperature of 25°C

\*11 Weight in the dry state without circulating fluids

\*12 The import of products using R404A as a refrigerant, even if they have a CE mark, into the EU is prohibited.


<sup>®</sup> 363

### **Cooling Capacity**




### Heating Capacity

### HRZ010-WS/010-W1S/010-W2S



### Pump Capacity (Thermo-chiller Outlet)


#### HRZ010-WS




The pump capacity of the HRZ010-W1S is same as that of the HRZ001-L1 group on page 360.

The pump capacity of the HRZ010-W2S is same as on page 362.

### HRZ010-W2S








\* When pump inverter is operating at frequency of 60 Hz (maximum).

### HRZ010-W1S




 When the circulating fluid flow is below 6 L/min, the in-built operation stop alarm will be activated. It is not possible to run the equipment. (common for all models)
 With flow control function by inverter



#### 364 INFORMATION cat43 2024-05

# HRZ Series Common Specifications

### Dimensions



						[mm]
	Model		Α	в	с	D
Fluorinated fluid type	Ethylene glycol type	Tap/Deionized water type	<b>~</b>			
HRZ001-H HRZ002-H	HRZ001-H1 HRZ002-H1	_	380	870	860	ø18.5 to 20.5
HRZ001-L HRZ002-L, W HRZ004-H HRZ008-H, W HRZ010-WS	HRZ001-L1 HRZ002-L1, W1 HRZ004-H1 HRZ008-H1, W1 HRZ010-W1S	HRZ001-L2 HRZ002-L2 HRZ004-L2 HRZ008-L2 HRZ010-W2S	380	870	950	ø18.5 to 20.5

(Dimensional tolerance of A, B, and C:  $\pm 10$  mm)

HRS НВЗН НЯЗН090 НИЗ200 НИЗО НИЗО90 НИЗ-В HRSE HRR HRL HRZ HRZD HRW HECR НЕС НЕВ НЕD Technical Data



# HRZ Series

#### Communication Functions (For details, please refer to our "Communication Specifications" information.)

-	Itput	-						
-	Item	•	ecifications					
	nector no.		8 for the connector location.)					
	on this product's side)	D-sub 25 P type, Female connector M2.6 x 0.45						
Fixin	g bolt size							
	Insulation method	Photocoupler						
Innut signal	Rated input voltage	24 VDC 21.6 VDC to 26.4 VDC						
Input signal	Operating voltage range							
	Rated input current	c	mA TYP					
	Input impedance		4.7 kΩ					
Insulation method			otocoupler					
	Rated load voltage		24 VDC					
Open collector	Operating load voltage range	21.6 VI	DC to 26.4 VDC					
output signal	Maximum load current		80 mA					
	Leakage current	0.1	mA or less					
	Surge protection		Diode					
Contact output signal	Rated load voltage	48 VAC or I	ess/24 VDC or less					
(Alarm signal)	Maximum load current		DC (Resistance load)					
Contact output signal	Rated load voltage		ess/24 VDC or less					
(EMO signal)	Maximum load current	800 mA AC/DC (Res	sistance load/Inductive load)					
Circu	it diagram	INT 24 VDC	1       24 VDC output (Output from the thermo-chiller)         14       24 VDC output (Output from the thermo-chiller)         24 VDC input (Supply from the user's equipment or thermo-chiller)*         24 VDC input (Supply from the user's equipment or thermo-chiller)*         24 COM input (Supply from the user's equipment or thermo-chiller)*         3       Setting at the time of shipment from factory         4       Recovery signal         16       —         4       Recovery signal         17       —         5       Operation condition signal 2         6       Operation condition signal         19       Warning signal       Output signal 3         20       Remote signal       Output signal 4         7       Fault signal       Output signal 3         20       Remote signal       Output signal 4         8       Temp ready signal       Output signal 5         18       Alarm signal       Alarm signal					

\*1 When using the power supply of the thermo-chiller, short circuit pins 1 and 2 and pins 14 and 15 respectively. When using the power supply of the user's equipment, connect the lead wires to pins 2 and 15 and short circuit

<sup>\*2</sup> The custom function is equipped for contact input/output. Using the custom function enables the user to set the signal type for contact input/output or pin assignment numbers. For details, please refer to the "Communication Specifications" information.



When using the power supply of the user's equipment, connect the lead wires to pins 2 and 15 and short circuit pins 14 and 15. Incorrect connections may cause a malfunction.

# Common Specifications HRZ Series

#### Serial RS-485

The serial RS-485 enables the following items to be written and read out. <Writing> Run/Stop Circulating fluid temperature setting Circulating fluid automatic recovery start/ stop\*1 <Readout> Circulating fluid present temperature Circulating fluid present temperature Circulating fluid flow Circulating fluid discharge pressure Circulating fluid discharge pressure Circulating fluid electric resistivity\*<sup>2</sup> Alarm occurrence information

Status (operating condition) information


function (option Z) is selected.

\*1 Only when the circulating fluid automatic recovery

\*2 Only when the DI control kit (option Y) is selected.

Item Specifications Connector no. P2 Connector type (on this product's side) D-sub 9 P type, Female connector Fixing bolt size M2.6 x 0.45 Standards EIA RS485 Protocol Modicon Modbus To the thermo-chiller User's equipment side 2 -0 Circuit diagram SD+ -7 SD-Internal circuit 5 0 SG

#### **Connector Location**




HRS 100/150 HRS090 HRS-R HRS200 HRSH090 HRSH HRSE HRR HRL HRZ HRZD HRW HECR HEC HEB HED Technical Data

HRS

# HRZ Series

### **Operation Display Panel**



No.	Description	Function
1	LCD	Operating condition of this unit/Circulating fluid discharge temperature/Circulating fluid flow/ Circulating fluid discharge pressure/Setting value/Alarm message, etc. are displayed.
2	[START/STOP] key	Starts/Stops the operation.
3	[RESET] key	Stops the alarm buzzing. Resets the alarm.
(4)	[SEL] key	Switches the display.
(5)	[ENT] key	Decides the settings.
6	[ <b>▲</b> ] [▼] key	Moves the cursor and changes the setting values.
$\overline{\mathcal{O}}$	[▶] key	Moves the cursor.
8	[REMOTE] lamp	Lights up when the unit is in the remote status.
9	[RUN] lamp	Lights up when the unit is in the operating status.
10	[ALARM] lamp	Lights up when the unit is alarming.

### Alarm

This unit can display 27 kinds of alarm messages as standard. Also, it can read out the serial RS-485 communication.

Alarm code	Alarm message	Operation status	Main reason
01	Water Leak Detect FLT	Stop	Liquid deposits in the base of this unit.
02	Incorrect Phase Error FLT	Stop	The power supply to this unit is incorrect.
03	RFGT High Press FLT	Stop	Pressure in the refrigeration circuit has exceeded the limitation.
04	CPRSR Overheat FLT	Stop	Temperature inside the compressor has increased.
05	Reservoir Low Level FLT	Stop	The amount of circulating fluid is running low.
06	Reservoir Low Level WRN	Continue	The amount of circulating fluid is running low.
07	Reservoir High Level WRN	Continue	Filling the circulating fluid too much.
08	Temp. Fuse Cutout FLT	Stop	Temperature of the circulating fluid tank is raised.
09	Reservoir High Temp. FLT	Stop	Temperature of the circulating fluid has exceeded the limitation.
11	Reservoir High Temp. WRN	Continue	Temperature of the circulating fluid has exceeded the limitation set by user.
12	Return Low Flow FLT	Stop	The circulating fluid flow has gone below 6 L/min.
13	Return Low Flow WRN	Continue	The circulating fluid flow has gone below the limitation set by user.
14	Heater Breaker Trip FLT	Stop	Protection device for the electric circuit of the heater is activated.
15	Pump Breaker Trip FLT	Stop	Protection device for the electric circuit of the circulating pump is activated.
16	CPRSR Breaker Trip FLT	Stop	Protection device for the electric circuit of the compressor is activated.
17	Interlock Fuse Cutout FLT	Stop	Overcurrent is flown to the control circuit.
18 <sup>*1, *2</sup>	DC Power Fuse Cutout WRN	Continue	Overcurrent has flowed to the solenoid valve.
19	FAN Motor Stop WRN	Continue	Cooling fan inside the compressor has stopped.
20	Internal Pump Time Out WRN	Continue	The internal pump continuously run for more than a certain period of time.
21	Controller Error FLT	Stop	The error occurred in the control systems.
22	Memory Data Error FLT	Stop	The data stored in the controller of this unit went wrong.
23	Communication Error WRN	Continue	The serial communications between this unit and user's system has been suspended
24 <sup>*2</sup>	DI Low Level WRN	Continue	DI level of the circulating fluid has gone below the limitation set by user.
25 <sup>*3</sup>	Pump Inverter Error FLT	Stop	An error has occurred in the inverter for the circulating pump.
26 <sup>*4</sup>	DNET Comm. Error WRN	Continue	The DeviceNet communications between this unit and user's system has been suspended
27 <sup>*4</sup>	DNET Comm. Error FLT	Stop	An error has occurred in the DeviceNet communication system of this unit.
28 <sup>*3</sup>	CPRSR INV Error FLT	Stop	An error has occurred in the inverter for the compressor.

\*1 Only for the circulating fluid automatic recovery specification (Option symbol Z)
\*2 Only for the DI control kit specification (Option symbol Y)

∗3 HRZ010-W□S only


\*4 Only for the DeviceNet communication specification (Option symbol D)



# HRZ Series Optional Accessories

## 1 Bypass Piping Set

When the circulating fluid goes below the rated flow, cooling capacity will be reduced and the temperature stability will be badly affected. In such a case, use the bypass piping set.



\* Necessary to be fitted by user.

Applicable model

Part no.

HRS

HRS 100/150 HRS090 HRS-R

HRS200


HRSH090

HRSH

HRSE


HRR

#### Bracket for earthquakes



# HRZ Series

## **3 4-Port Manifold**



**SMC** 


# 4 DI Filter

This is the ion replacement resin to maintain the electric resistivity of the circulating fluid.

Users who selected the DI control kit (option Y) need to purchase the DI filter separately.

Part no.	Applicable model				
HRZ-DF001	Common for all models which can select the DI control kit. (option Y)				

The DI filters are consumable. Depending on the status (electric resistivity set value, circulating fluid temperature, piping volume, etc.), product life cycles will vary accordingly.




Weight: Approx. 20 kg

# **5** Insulating Material for DI Filter

When the DI filter is used at a high-temperature, we recommend that you use this insulating material to protect the radiated heat from the DI filter or possible burns. When the DI filter is used at a low-temperature, we also recommend that you use this to prevent heat absorption from the DI filter and to avoid forming condensation.


Part no.	Applicable model
HRZ-DF002	Common for all models which can select the DI control kit. (option Y)



### **(6) 60% Ethylene Glycol Aqueous Solution**

This solution can be used as a circulating fluid for ethylene glycol-type thermo-chillers. (Capacity: 10 L)


Part no.	Applicable model
HRZ-BR001	Common for all ethylene glycol-type models



### **⑦** Concentration Meter

This meter can be used to control the condensation of ethylene glycol solution regularly.

Part no.	Applicable model
HRZ-BR002	Common for all ethylene glycol-type models









#### Options have to be selected when ordering the thermo-chiller. It is not possible to add them after purchasing the unit.

#### Option symbol

#### Analog Communication



#### Analog communication

In addition to the standard contact input/output signal communication and the serial RS-485 communication, analog communication function can be added.


The analog communication function enables to write and read out the following items.

<Writing> Circulating fluid temperature setting <Readout> Circulating fluid present temperature Electric resistivity<sup>\*1</sup>

\*1 Only when the DI control kit (option Y) is selected.

Scaling voltage - circulating fluid temperature can be set arbitrarily by user.

For details, please refer to our "Communication Specifications" information.





Select this option if you want to maintain the electric resistance ratio (DI level) of the circulating fluid at a certain level. However, some components have to be fitted by user. For details, refer to specification table for this option.


Please note that this is not applicable to the fluorinated liquid type.

Applicable model		HRZ00□-L1-Y HRZ00□-H1-Y HRZ00□-W1-Y HRZ010-W1S-Y	HRZ00□-L2-Y HRZ010-W2S-Y	
Allowable circulating fluid	—	60% ethylene glycol aqueous solution	Deionized water	
DI level display range	MΩ⋅cm	n 0 to 20		
DI level set range	MΩ⋅cm	n 0 to 2.0*1		
DI level reduction alarm set range	MΩ⋅cm	0 to 2.0		

1 The DI filter is needed to control the DI level. (SMC Part No.: HRZ-DF001)

SMC

Please purchase additionally because the DI filter is not included in this option. Also, if necessary, additionally purchase the insulating material for the DI filter. (SMC Part No.: HRZ-DF002)



- Install the DI filter outside the thermo-chiller for piping. Secure the space for installing the DI filter on the rear side of the thermo-chiller.
- \* It may go outside of the temperature stability range of  $\pm 0.1^{\circ}$ C when this option is used in some operating conditions.

Option symbol

#### DeviceNet Communication

HRZ \_\_\_\_\_DeviceNet communication


# DeviceNet® is a registered trademark of ODVA. Inc.

In addition to the standard contact input/output signal communication and the serial RS-485 communication, DeviceNet function can be added. DeviceNet function enables to write and read out the following items.

<Writing> Run/Stop Circulating fluid temperature setting Circulating fluid automatic recovery start/stop<sup>\*1</sup> <Readout> Circulating fluid present temperature Circulating fluid flow Circulating fluid discharge pressure Electric resistivity\*<sup>2</sup> Alarm occurrence information Status (operating condition) information

\*1 Only when the circulating fluid automatic recovery function (option Z) is selected.
 \*2 Only when the DI control kit (option Y) is selected.

For details, please refer to our "Communication Specifications" information.



SI unit only

are displayed in SI units [MPa/°C] only. If this option is not selected, a product with a unit selection function will be provided by default. \* No change in external dimensions

#### Option symbol Ζ

**Circulating Fluid Automatic Recovery** 

HRZ **──**─**─**Z

Circulating fluid automatic recovery

Select this option for users who want to use the circulating fluid automatic recovery function.


The automatic recovery function is a device which can recover the circulating fluid inside pipings into a sub-tank of the thermo-chiller by the external communication or operating display panel. Some components need to be fitted by user. For details, please refer to the "Product Specifications" information for these options.

Applicable model		HRZ001-H-Z HRZ001-H1-Z HRZ002-H-Z HRZ002-H1-Z	HRZ001-L-Z HRZ002-L-Z HRZ004-H-Z HRZ008-H-Z HRZ001-L2-Z HRZ004-L2-Z HRZ002-W-Z HRZ008-W-Z HRZ010-WS-Z HRZ010-W2S-Z	HRZ001-L1-Z HRZ002-L1-Z HRZ004-H1-Z HRZ008-H1-Z HRZ002-L2-Z HRZ008-L2-Z HRZ002-W1-Z HRZ008-W1-Z HRZ010-W1S-Z
Circulating fluid recoverable volume*1	L	15	16	
Purge gas		Nitrogen gas		
Purge gas supply port		Self-align fitting for O.D. ø8*2		Ø8 <sup>*2</sup>
Purge gas supply pressure	MPa	0.4 to 0.7		
Purge gas filtration	μm	0.01 or less		
Regulator set pressure	MPa	0.15 to 0.3* <sup>3</sup>		
Recoverable circulating fluid temperature	°C	10 to 30		
Recovery start/stop	—	Start: External communi	cation*4 or operation dis	splay panel/Stop: Automatic
Timeout error	sec	Timer from recovery start to completion Stops recovering when the timer turns to set time. Possible set range: 60 to 300, at the time of shipping from the factory:		rns to set time.
Height difference with the user system side	m	10 or less		

\*1 This is the space volume of the sub-tank when the liquid level of the circulating fluid is within the specification. Guideline of the recovery volume is 80% of the circulating fluid recoverable volume.

\*2 Before piping, clean inside the pipings with air blow, etc. Use the piping with no dust generation by purge gas. When using resin tube, where necessary, use insert fittings, etc. in order not to deform the tubings when connecting to self-align fittings.

\*3 At the time of shipping from factory, it is set to 0.2 MPa.
\*4 For details, please refer to our "Communication Specifications" information.



HRS

374 ® INFORMATION cat43 2024-05





# HRZ Series Specific Product Precautions 1

Be sure to read this before handling the products. Refer to page 513 for safety instructions and pages 514 to 517 for temperature control equipment precautions.

#### Design

# A Warning

#### 1. This catalog shows the specifications of a single unit.

- 1. For details, please refer to our "Product Specifications" and thoroughly consider the adaptability between the user's system and this unit.
- Although a protection circuit as a single unit is installed, the user is requested to carry out a safety design for the whole system.

Selection

# **A**Caution

### 1. Model selection

In order to select the correct thermo-chiller model, the amount of thermal generation from the user's system, the operating circulating fluid, and its circulating flow are required. Select a model, by referring to the guideline to model selection on page 351.

#### 2. Option selection

Options have to be selected when ordering the thermo-chiller. It is not possible to add them after purchasing the unit.

#### Handling

# **Marning**

### 1. Thoroughly read the operation manual.

Read the operation manual completely before operation, and keep the manual where it can be referred to as necessary.

### **Operating Environment/Storage Environment**

# **A** Caution

# 1. Do not use in the following environment because it will lead to a breakdown.

- 1. Environment like written in "Temperature Control Equipment Precautions."
- 2. Locations where spatter will adhere to when welding.
- 3. Locations where it is likely that the leakage of flammable gas may occur.
- 4. Locations where the ambient temperature exceeds the limits as mentioned below.
  - During operation 10°C to 35°C
  - During storage  $0^{\circ}$ C to  $50^{\circ}$ C (but as long as water or circulating fluid are not left inside the pipings)
- Locations where the ambient relative humidity exceeds the limit as mentioned below.
  - During operation 30% to 70%
  - During storage 15% to 85%
- (Inside the operation facilities) locations where there is not sufficient space for maintenance.
- 7. In locations where the ambient pressure exceeds the atmospheric pressure.
- 2. The Thermo-chiller does not have clean room specification. It generates dust from the pump inside the unit and the cooling fan for the unit inside.

#### **Circulating Fluid**

# **A**Caution

1. Avoid oil or other foreign matter entering the circulating fluid.

#### **Circulating Fluid**

- 2. Use ethylene glycol that does not contain additives such as preservatives.
- 3. The condensation of ethylene glycol aqueous solution must be 60% or less. If the density is too high, the pump will be overloaded, resulting in occurrence of "Pump Breaker Trip FLT." Also, if the density is to low, the unit will freeze at lower temperatures, resulting in product failure.
- 4. Avoid water moisture entering the fluorinated fluid. Otherwise, the unit will freeze, resulting in product failure.
- 5. Use tap water (including for diluting ethylene glycol aqueous solution) which must meet the water quality standards as mentioned below.

### Tap Water (as Circulating Water) Quality Standards

The Japan Refrigeration and Air Conditioning Industry Association JRA GL-02-1994 "Cooling water system – Circulating type – Supply water"

JHA	JL-02-1994 COUIIING Water S	stem - Oi	culating type – Supp	iy wale	;1
				Influ	ence
	Item	Unit	Standard value	Corrosion	Scale generation
	pH (at 25°C)	—	6.0 to 8.0	0	0
_	Electric conductivity (25°C)	[µS/cm]	100*1 to 300*1	0	0
E Chloride ion (Cl⁻)		[mg/L]	50 or less	0	
Standard item	Sulfuric acid ion (SO42-)	[mg/L]	50 or less	0	
nda	Acid consumption amount (at pH4.8)	[mg/L]	50 or less		0
Sta	Total hardness	[mg/L]	70 or less		0
	Calcium hardness (CaCO <sub>3</sub> )	[mg/L]	50 or less		0
	Ionic state silica (SiO <sub>2</sub> )	[mg/L]	30 or less		0
-	Iron (Fe)	[mg/L]	0.3 or less	0	0
item	Copper (Cu)	[mg/L]	0.1 or less	0	
ce	Sulfide ion (S2-)	[mg/L]	Should not be detected.	0	
eren	Ammonium ion (NH <sub>4</sub> +)	[mg/L]	0.1 or less	0	
Reference	Residual chlorine (Cl)	[mg/L]	0.3 or less	0	
L.	Free carbon (CO <sub>2</sub> )	[mg/L]	4.0 or less	0	

\*1 In the case of [M $\Omega$ ·cm], it will be 0.003 to 0.01.

O: Factors that have an effect on corrosion or scale generation.
Even if the water quality standards are met, complete prevention of corrosion

• Even in the water quality standards are met, complete prevention of corrosio is not guaranteed.



# HRZ Series Specific Product Precautions 2

Be sure to read this before handling the products. Refer to page 513 for safety instructions and pages 514 to 517 for temperature control equipment precautions.

#### **Facility Water Supply**

# **Warning**

#### <Water-cooled refrigeration>

1. The water-cooled refrigeration type thermo-chiller radiates heat to the facility water.

Prepare the facility water system that satisfies the facility water specifications below.

2. When using tap water as facility water, use tap water that conforms to the appropriate water quality standards. Use tap water that conforms to the standards shown below.

#### <Tap Water (as Facility Water) Quality Standards>

The Japan Refrigeration and Air Conditioning Industry Association JRA GL-02-1994 "Cooling water system – Circulation type – Circulating water"

JRA GL-02-1994 "Cooling water system – Circulation type – Circulating water"			alei		
				Influence	
	ltem	Unit	Standard value	Corrosion	Scale generation
	pH (at 25°C)	—	6.5 to 8.2	0	0
_	Electric conductivity (25°C)	[µS/cm]	100*1 to 800*1	0	0
item	Chloride ion (CI-)	[mg/L]	200 or less	0	
	Sulfuric acid ion (SO42-)	[mg/L]	200 or less	0	
Standard	Acid consumption amount (at pH4.8)	[mg/L]	100 or less		0
star	Total hardness	[mg/L]	200 or less		0
0	Calcium hardness (CaCO <sub>3</sub> )	[mg/L]	150 or less		0
	Ionic state silica (SiO <sub>2</sub> )	[mg/L]	50 or less		0
E	Iron (Fe)	[mg/L]	1.0 or less	0	0
item	Copper (Cu)	[mg/L]	0.3 or less	0	
Ce	Sulfide ion (S2-)	[mg/L]	Should not be detected.	0	
Len	Ammonium ion (NH <sub>4</sub> +)	[mg/L]	1.0 or less	0	
Reference	Residual chlorine (CI)	[mg/L]	0.3 or less	0	
<u> </u>	Free carbon (CO <sub>2</sub> )	[mg/L]	4.0 or less	0	

\*1 In the case of [M $\Omega$ ·cm], it will be 0.001 to 0.01.

O: Factors that have an effect on corrosion or scale generation.

- Even if the water quality standards are met, complete prevention of corrosion is not guaranteed.
- 3. Set the supply pressure between 0.3 to 0.7 MPa. Ensure a pressure difference at the facility water inlet/outlet of 0.3 MPa or more.

If the supply pressure is high, it will cause water leakage. If the supply pressure and pressure difference at the facility water inlet/outlet is low, it will cause an insufficient flow rate of the facility water, and poor temperature control.

#### Transportation/Carriage/Movement


# \land Warning

#### 1. Transporting with forklift

- 1. It is not possible to hang this product.
- The fork insertion position is either on the left side face or right side face of the unit. Be careful not to bump the fork against a caster or level foot and be sure to put through the fork to the opposite side.
- 3. Be careful not to bump the fork to the cover panel or piping ports.

# 2. Transporting with casters

- 1. This product is heavy and should be moved by at least two people.
- Do not grip the pipings on the rear side or the handles of the panel.



#### Mounting/Installation

# A Caution

- 1. Avoid using this product outdoors.
- 2. Install on a rigid floor which can withstand this product's weight.
- 3. Install a suitable anchor bolt for the anti-quake bracket taking into consideration the user's floor material.
- 4. Avoid placing heavy objects on this product.

Piping

# **▲** Caution

 Regarding the circulating fluid and facility water pipings, consider carefully the suitability for temperature, circulating fluid and facility water. If the operating performance specifications are regularly exceeded, the pipings

may burst during operation.

Also, the use of corrosive materials such as aluminum or iron for fluid contact parts, such as piping, may not only lead to clogging or leakage in the circulating fluid and facility water circuits but also refrigerant leakage and other unexpected problems. Provide protection against corrosion when you use the product.

2. The surface of the circulating fluid pipings should be covered with the insulating materials which can effectively confine the heat. Absorbing the heat from the surface of pipings may reduce the cooling capacity

performance and the heating capacity may be shortened due to heat radiation. 3. When using fluorinated liquid as the circulating

## fluid, do not use pipe tape.

Liquid leakage may occur around the pipe tape. For sealant, we recommend that you use the following sealant: SMC Part No., HRZ-S0003 (Silicone sealant)

- 4. For the circulating fluid pipings, use clean pipings which have no dust, oil or water moisture inside the pipings, and blow with air prior to undertaking any piping works. If any dust, oil or water moisture enters the circulating fluid circuit, inferior cooling performance or equipment failure due to frozen water may occur, resulting in bubbles in the circulating fluid inside the tank.
- 5. The reciprocating total volume of the circulating fluid pipings must be less than the volume of the sub-tank. Otherwise, when the equipment is stopped, the in-built alarm may activate or the circulating fluid may leak from the tank. Refer to the specifications table for the sub-tank volume.
- 6. Select the circulating fluid pipings which can exceed the required rated flow.

For the rated flow, refer to the pump capacity table.

- 7. For the circulating fluid piping connection, install a drain pan just in case the circulating fluid may leak.
- 8. Do not return the circulating fluid to the unit by installing a pump in the user system.
- 9. The facility water flow rate is adjusted automatically according to the operating conditions.


In addition, the facility water return temperature is 60°C at maximum.

#### **Electrical Wiring**

# A Caution

- 1. Power supply and signal cable should be prepared by user.
- 2. Provide a stable power supply which is not affected by surge or distortion.

If the voltage increase ratio (dV/dt) at the zero cross should exceed 40 V/200  $\mu$ sec., it may result in malfunction.



tion side



# HRZ Series Specific Product Precautions 3

Be sure to read this before handling the products. Refer to page 513 for safety instructions and pages 514 to 517 for temperature control equipment precautions.

#### **Electrical Wiring**

# **A** Caution

# 3. This product is installed with a breaker with the following operating characteristics.

For the user's equipment (inlet side), use a breaker whose operating time is equal to or longer than the breaker of this product. If a breaker with shorter operating time is connected, the user's equipment could be cut off due to the inrush current of the motor of this product.

#### **Breaker Operating Characteristics**

#### Applicable model

 HRZ001-L
 HRZ001-H

 HRZ002-L
 HRZ002-H

 HRZ001-L1
 HRZ004-H

 HRZ002-L1
 HRZ008-H

 HRZ001-L2
 HRZ001-H1


 HRZ002-L2
 HRZ002-H1

 HRZ004-L2
 HRZ002-H1


 HRZ008-L2
 HRZ008-H1

 HRZ008-L2
 HRZ008-H1

 HRZ008-L2
 HRZ008-H1



HRZ010-WS HRZ010-W1S HRZ010-W2S



#### Operation

# **A**Caution

#### 1. Confirmation before operation

- 1. The circulating fluid should be within the specified range of "HIGH" and "LOW."
- 2. Be sure to tighten the cap for the circulating fluid port until the click sound is heard.

#### 2. Emergency stop method

In the case of an emergency, press down the EMO switch which is fitted on the front face of this product.

Operation Restart Time/Operation and Suspension Frequency

HRS

HRS-R

HRS 100/150 HRS090

HRS200

HRSH090

HRSH

HRSE

HRR

HRL

HRZ

HRZD

HRW

HECR

HEC

HEB

# A Caution

- 1. Wait five minutes or more before restarting operation after it has been stopped. If the operation is restarted within five minutes, the protection circuit may activate and the operation may not start properly.
- 2. Operation and suspension frequency should not exceed 10 times per day. Frequently switching between operation and suspension may result in the malfunction of the refrigeration circuit.

Maintenance

# \land Warning

- 1. Do not operate the switch with wet hands or touch electrical parts such as an electrical plug. This will lead to an electrical shock.
- 2. Do not splash water directly on this product for cleaning. This will lead to an electrical shock or a fire.
- 3. When the panel was removed for the purpose of inspection or cleaning, mount the panel after works were done.

If the panel is still open, or running the equipment with the panel removed, it may cause an injury or electric shock.

# ▲ Caution

- 1. In order to prevent a sudden product failure of the unit, replace the replacement parts every 36 months.
- 2. Perform an inspection of the circulating fluid every 3 months.
  - 1. In the case of fluorinated fluids:
    - Discharge the circulating liquid and avoid any dirty objects, or water moisture, or foreign matter entering the system.
  - 2. In the case of ethylene glycol aqueous solution: Maintain the condensation at 60%.
  - In the case of tap water, deionized water: Replacement is recommended.
- 3. Check the water quality of cooling water every 3 months. Regarding the water quality standards for cooling water, refer to "Temperature Control Equipment Precautions."

#### ■ Refrigerant with GWP reference

	Global warming potential (GWP)			
Refrigerant	Regulation (EU) No 517/2014 (Based on the IPCC AR4)	Revised Fluorocarbons Recovery and Destruction Law (Japanese law)		
R134a	1,430	1,430		
R404A	3,922	3,920		
R407C	1,774	1,770		
R410A	2,088	2,090		
R448A	1,387	1,387		

 This product is hermetically sealed and contains fluorinated greenhouse gases (HFC). When this product is sold on the market in the EU after January 1, 2017, it needs to be compliant with the quota system of the F-Gas Regulation in the EU.
 \* See specification table for refrigerant used in the product.

Derinated e market with the **Jata** 2024-05