
Process Pump Automatically Operated Type (Internal Switching Type) Air Operated Type (External Switching Type)

PA3000 Series



How to Order



Specifications

Model		PA3110	PA3120	PA3210	PA3220	PA3113	PA3213
Actuation	ı		Automatica	lly operated		Air op	erated
Port size	Main fluid suction discharge port		Rc, NF	PT, G, NPTF	3/8" Female	thread	
POIT SIZE	Pilot air supply/exhaust port		Rc, NF	PT, G, NPTF	1/4" Female	thread	
	Body wetted areas	AD	C12	SC	S14	ADC12	SCS14
Material	Diaphragm	PTFE	NBR	PTFE	NBR	PT	FE
	Check valve			PTFE	, PFA		
Discharge	e rate		1 to 20	L/min		0.1 to 1	2 L/min
Average of	discharge pressure		0 to 0.	6 MPa		0 to 0.	4 MPa
Pilot air p	ressure		0.2 to 0	1.7 MPa		0.1 to 0).5 MPa
Air consu	mption	Max. 200 L/min (ANR) or less			Max. 150 L/min (ANR) or less		
Suction ^{lide 1)}	Dry	1 m (Interior of pump dry)					
range	Wet		U	to 6 m (liqui	id inside pum	ıp)	
Noise		80 dB (A) or less (Option: with silencer, AN20)				72 dB (A) or less (excluding the noise from the quick exhaust and solenoid valve)	
Withstand	d pressure	1.05 MPa			0.75	MPa	
Diaphragi	m life	100 million times 50 million times 100 million times 50 million times 50 million times					on times
Fluid tem	perature	0 to 60°C (No freezing)					
Ambient t	emperature	0 to 60°C (No freezing)					
Maximum viscosity		1000 mPa⋅s					
Recommended operating cycle		-			1 to 7 Hz (0.2 to 1 Hz also possible depending on conditions) Note 2)		
	olenoid valve ^{Note 3)} nded Cv factor	_			0.	20	
Weight		1.7	' kg	2.2	kg	1.7 kg	2.2 kg
Mounting	orientation	Horizontal (with mounting foot at bottom)					
Packagin	g	General environment					

^{*} Each of the values above are for normal temperatures and when the transferred fluid is fresh water.

Since a large quantity of liquid will be pumped out, use a suitable throttle in the discharge port if problems occur. Note 3) With a low number of operating cycles, even a valve with a small Cv factor can be operated.



Automatically operated type

FLUID IN Air operated type

Products complying with ATEX

With air operated reset port Note)

With operating cycle counting port Note)

Note) For automatically operated type only.

Made to order specifications (For details, refer to pages 563 and 564)

FLUID OUT

^{*} Refer to page 558 for maintenance parts.

^{*} For related products, refer to pages 622 and 623. Note 1) With cycles at 2 Hz or more

Note 2) After initial suction of liquid operating at 1 to 7 Hz, it can be used with operation at lower cycles.

Process Pump

Automatically Operated Type (Internal Switching Type)
Air Operated Type (External Switching Type)

PA5000 Series



Applicable actuation

operate

•

Automatically

operated

Option

Port size
Symbol Port size

NPT G NPTF

Thread type

N

Body only

With silencer*

* For AIR EXH: AN20-□02





		A	J		Ш	L
ody	wet	ted	area	as d		

DA 5 1

Ma	iterial	of body wetted areas
	Symbol	Material of body wetted areas
	1	ADC12 (Aluminum)
	2	SCS14 (Stainless steel)

Diaphragm material

ı		D: 1	Applicable actuation			
	Symbol	Diaphragm material	Automatically operated	Air operated		
ı	1	PTFE	•	•		
	2	NBR	•	_		

Actuation

Symbol	Actuation
0	Automatically operated
3	Air operated

A new type of PA5000 with a polypropylene

P	A
P/	(P)

PA(P)


PB

PAF

PA□ PB

AIR SUP	FLUID OUT
AIR EXH ✓	FLUID IN
Automatically ope	erated type

Symbol





Made to order specifications (For details, refer to pages 563 and 564)

Products complying with ATEX
With air operated reset port Note)
With operating cycle counting port Note

Note) For automatically operated type only

body is no	ody is now available. Click here for details.						
	Model	PA5110	PA5120	PA5210	PA5220	PA5113	PA5213
Actuation	Actuation		Automatica	lly operated		Air operated	
Port size	Main fluid suction discharge port		Rc, NPT, G, NPTF 1/2", 3/4" Female thread				
FUIT SIZE	Pilot air supply/exhaust port		Rc, NF	PT, G, NPTF	1/4" Female	thread	
	Body wetted areas	ADO	C12	SC	SCS14		SCS14
Material	Diaphragm	PTFE NBR		PTFE	NBR	PT	FE
	Check valve			PTFE	, PFA		
Discharge	e rate		5 to 45	L/min		1 to 24	L/min
Average of	discharge pressure		0 to 0.	6 MPa		0 to 0.	4 MPa
Pilot air p	ressure		0.2 to 0	.7 MPa		0.1 to 0).5 MPa
Air consu		M	ax. 300 L/mir	n (ANR) or le	SS	Max. 250 L/mir	n (ANR) or less
Suction Note 1)	Drv	Up to 2 m			Up to 0.5 m		
lifting	Diy	(Interior of pump dry)				(Interior of pump dry)	
range	Wet		Up	to 6 m (Liqu	id inside pun		
Noise		78 dB (A) or less (Option: with silencer, AN 20)				72 dB (A) or less (excluding the noise from the quick exhaust and solenoid valve)	
Withstand	d pressure	, -	·	MPa		0.75	
Diaphragi		50 million times					
	fluid temperature	0 to 60°C (No freezing)					
Ambient t	emperature	0 to 60°C (No freezing)					
Maximum	viscosity	1000 mPa⋅s					
Recommended operating cycle		-			1 to 7 Hz (0.2 to 1 Hz also possible depending on conditions) Note 2)		
Pilot air solenoid valve Note 3) recommended Cv factor		_			0.45		
Weight		3.5	kg	6.5	kg	3.5 kg	6.5 kg
Mounting	orientation	Horizontal (with mounting foot at bottom)					
Packagin	g			General er	vironment		
* Each of th	ne values above are f	or normal ter	mperatures a	nd when the	transferred f	luid is fresh w	ater.

- Each of the values above are for normal temperatures and when the transferred fluid is fresh water
- * Refer to page 558 for maintenance parts.
- * For related products, refer to pages 622 and 623

Note 1) With cycles at 2 Hz or more


Note 2) After initial suction of liquid operating at 1 to 7 Hz, it can be used with operation at lower cycles.

Since a large quantity of liquid will be pumped out, use a suitable throttle in the discharge port if problems occu


Performance Curve: Automatically Operated Type

A new type of PA5000 with a polypropylene body is now available. Click here for details.

PA3 0 Flow Rate Characteristics



PA5 0 Flow Rate Characteristics



Selection from Flow Rate Characteristic Graph (PA3□□0)

Required specifications example:

Find the pilot air pressure and pilot air consumption for a discharge rate of 6 L/min and a discharge pressure of 0.25 MPa. <The transfer fluid is fresh water (viscosity 1 mPa·s, specific gravity 1.0).>

* If the total lifting height is required instead of the discharge pressure, a discharge pressure of 0.1 MPa corresponds to a total lift of 10 m.


Selection procedures:

- 1. First mark the intersection point for a discharge rate of 6 L/min and a discharge pressure of 0.25 MPa.
- 2. Find the pilot air pressure for the marked point. In this case, the point is between the discharge curves (solid lines) for SUP = 0.3 MPa and SUP = 0.4 MPa, and based on the proportional relationship to these lines, the pilot air pressure for this point is approximately 0.38 MPa.
- 3. Next find the air consumption rate. Since the marked point is below the curve for 50 L/min (ANR), the maximum rate will be about 50 L/min (ANR).

∧ Caution

- 1. These flow rate characteristics are for fresh water (viscosity 1 mPa·s, specific gravity 1.0).
- The discharge rate differs greatly depending on properties (viscosity, specific gravity) of the fluid being transferred and operating conditions (lifting range, transfer distance), etc.
- Use 0.75 kW per 100 L/min of air consumption as a guide for the relationship of the air consumption to the compressor.

Viscosity Characteristics (Flow rate correction for viscous fluids)



Selection from Viscosity Characteristic Graph

Required specifications example:

Find the pilot air pressure and pilot air consumption for a discharge rate of 2.7 L/min, and a viscosity of 100 mPa s. Selection procedures:

- First find the ratio of the discharge rate for fresh water when viscosity is 100 mPa·s from the graph below. It is determined to be 45%.
- 2. Next, in the required specification example, the viscosity is 100 mPa·s and the discharge rate is 2.7 L/min. Since this is equivalent to 45% of the discharge rate for fresh water, 2.7 L/min + 0.45 = 6 L/min, indicating that a discharge rate of 6 L/min is required for fresh water.
- Finally, find the pilot air pressure and pilot air consumption based on selection from the flow characteristic graphs.

Viscosities up to 1000 mPa·s can be used. Dynamic viscosity ν = Viscosity μ /Density ρ .

$$v = \frac{\mu}{\rho}$$

 $v(10^{-3} \, \text{m}^2/\text{s}) = \mu(\text{mPa}\cdot\text{s})/\rho(\text{kg/m}^3)$

Performance Curve: Air Operated Type

A new type of PA5000 with a polypropylene body is now available. Click here for details.


PA

PA(P)

PAX

PB PAF


PB



Я

10

PA5 ☐ 13 Flow Rate Characteristics




Discharge pressure (MPa)

PA3□13 Air Consumption

2

4

0



Discharge rate (L/min)

Selection from Flow Rate Characteristic Graph (PA3□13)


Required specification example: Find the pilot air pressure and pilot air consumption for a discharge rate of 6 L/min. <The transfer fluid is fresh water (viscosity 1 mPa·s, specific gravity 1.0).>

Note 1) If the total lifting height is required instead of the discharge pressure, a discharge pressure of 0.1 MPa corresponds to a total lift of 10 m.


Selection procedures:

- 1. First mark the intersection point for a discharge rate of 6 L/min and a discharge pressure of 0.1 MPa.
- 2. Find the pilot air pressure for the marked point. In this case, the point is between the discharge curves (solid lines) for SUP = 0.2 MPa and SUP = 0.3MPa, and based on the proportional relationship to these lines, the pilot air pressure for this point is approximately 0.25 MPa.

PA5□13 Air Consumption



- 1. These flow rate characteristics are for fresh water (viscosity 1 mPa·s, specific gravity 1.0).
- The discharge rate differs greatly depending on properties (viscosity, specific gravity) of the fluid being transferred and operating conditions (density, lifting range, transfer distance).



Calculating Air Consumption (PA3 13)

Find the air consumption for operation with a 4 Hz switching cycle and pilot air pressure of 0.3 MPa from the air consumption graph. Selection procedures:

1. Look up from the 4 Hz switching cycle to find the intersection with SUP = 0.3 MPa. From the point just found, draw a line to the Y-axis to find the air consumption. The result is approximately 50 L/min (ANR).

Selection from Viscosity Characteristic Graph

Required specification example: Find the pilot air pressure and pilot air consumption for a discharge rate of 2.7 L/min, and a viscosity of 100 mPa-s.

Selection procedures:

- 1. First find the ratio of the discharge rate for fresh water when viscosity is 100 mPa·s from the graph below. It is determined to be 45%
- Next, in the required specification example, the viscosity is 100m Pa·s and the discharge rate is 2.7 L/min. Since this is equivalent to 45% of the discharge rate for fresh water, 2.7 L/min ÷ 0.45 = 6 L/min, indicating that a discharge rate of 6 L/min is required for fresh water.
- 3. Finally, find the pilot air pressure and pilot air consumption based on selection from the flow characteristic graphs.


Viscosities up to 1000 mPa·s can be used. Dynamic viscosity $v = Viscosity \mu/Density \rho$. $v = \frac{\mu}{\rho}$

 $v(10^{-3} \text{ m}^2/\text{s}) = \mu(\text{mPa}\cdot\text{s})/\rho(\text{kg/m}^3)$

PA Series

Working Principle

A new type of PA5000 with a polypropylene body is now available. Click here for details.




Control unit

- When air is supplied, it passes through the switching valve and enters drive chamber B.
- 2. Diaphragm B moves to the right, and at the same time diaphragm A also moves to the right pushing pilot valve A.
- 3. When pilot valve A is pushed, air acts upon the switching valve, drive chamber A switches to a supply state, and the air which was in drive chamber B is exhausted to the outside.
- 4. When air enters drive chamber A, diaphragm B moves to the left pushing pilot valve B.
- 5. When pilot valve B is pushed, the air which was acting upon the switching valve is exhausted, and drive chamber B once again switches to a supply state. A continuous reciprocal motion is generated by this repetition.

Drive unit

- 1. When air enters drive chamber B, the fluid in pump chamber B is forced out, and at the same time fluid is sucked into pump chamber A.
- 2. When the diaphragm moves in the opposite direction, the fluid in pump chamber A is forced out, and fluid is sucked into pump chamber B.
- 3. Continuous suction and discharge is performed by the reciprocal motion of the diaphragm.



- 1. When air is supplied to P1 port, it enters drive chamber A.
- 2. Diaphragm A moves to the left, and at the same time diaphragm B also moves to the left.
- 3. The fluid in pump chamber A is forced out to the discharge port, and the fluid is sucked into pump chamber B from the suction port.
- 4. If air is supplied to the P2 port, the opposite will occur. Continuous suction and discharge of fluid is performed by repeating this process with the control of an external solenoid valve (5 port valve).

Maintenance Parts

While it is not possible to disassemble this product without voiding the warranty, if disassembly is to be carried out anyway due to necessity, be sure to follow the maintenance procedures.

When carrying out this work, wear appropriate protective equipment.

PA3000/5000 Series


Description		PA3000 series		PA5000 series			
Description	PA3□10	PA3□20	PA3□13	PA5□10	PA5□20	PA5□13	
Diaphragm kit	KT-PA3-31	KT-PA3-32	KT-PA3-31	KT-PA5-31	KT-PA5-32	KT-PA5-31	
Check valve kit	KT-PA3-36			KT-PA5-36			
Switching valve assembly kit	KT-PA3-37□ Note) -		_	_			
Switching valve parts kit	_		KT-P	A5-37	_		
Pilot valve kit	KT-PA5-38		_	KT-PA5-38		_	
Manual cap assembly kit	KT-PA3-45		_	KT-PA5-45		_	

Note) One of Nil, N, F or T is entered as a thread symbol.



Piping and Operation: Automatically Operated Type

A new type of PA5000 with a polypropylene body is now available. Click here for details.



⚠ Caution

Mounting posture of the pump is set with the mounting bracket facing downward. Air to be supplied to the air supply port <AIR SUP> should be cleaned and filtered through AF filter, etc. Air with foreign matter or drainage etc. will have negative effects on the built-in directional control valve and will lead to malfunction. When air needs additional purification, use a filter (AF series), and a mist separator (AM series) together.


Maintain the proper tightening torque for fittings and mounting bolts, etc. Looseness can cause problems such as fluid and air leaks, while over tightening can cause damage to threads and parts, etc.

Operation

<Starting and Stopping> Refer to circuit example (1)


- Connect air piping to the air supply port <AIR SUP> and connect piping for the fluid to be transferred to the suction port <FLUID IN> and the discharge port <FLUID OUT>.
- 2. Using a regulator, set the pilot air pressure within the range of 0.2 to 0.7 MPa. Then, the pump operates when power is applied to the 3 port solenoid valve of the air supply port <AIR SUP>, the sound of exhaust begins from the air exhaust port <AIR EXH> and fluid flows from the suction port <FLUID IN> to the discharge port <FLUID OUT>.
 - At this time, the throttle on the discharge side is in an open state. The pump performs suction with its own power even without priming. (Dry state suction lifting range: max. 1 m) To restrict exhaust noise, attach a silencer (AN20-02: option) to the air exhaust port <AIR EXH>.
- 3. To stop the pump, exhaust the air pressure being supplied to the pump by the 3 port solenoid valve of the air supply port <AIR SUP>. The pump will also stop if the throttle on the discharge side is closed.
- <Discharge Flow Rate Adjustment>
- To adjust the flow rate from the discharge port <FLUID OUT>, use the throttle connected to the discharge side. Refer to circuit example
 Note that this product cannot be used as a fixed quantity liquid dispense pump.
- 2. When operating with a discharge flow rate below the specification range, provide a by-pass circuit from the discharge side to the suction side to ensure the minimum flow rate inside the process pump. With a discharge flow rate below the minimum flow rate, the process pump may stop due to unstable operation. Refer to circuit example (2). (Minimum flow rates: PA3000 1 L/min, PA5000 5 L/min)
 Reset Button>

When the pump stops during operation, press the reset button. This makes it possible to restore operation in case the switching valve becomes clogged due to foreign matter in the supply air.



Piping and Operation: Air Operated Type


A new type of PA5000 with a polypropylene body is now available. Click here for details.




Maintain the proper tightening torque for fittings and mounting bolts, etc. Looseness can cause problems such as fluid and air leaks, while over tightening can cause damage to threads and parts, etc.


Operation

- <Starting and Stopping> Refer to circuit example
- Connect air piping Note 1) to the pilot air supply port <P1>, <P2> and connect piping for the fluid to be transfered to the suction port <FLUID IN> and the discharge port <FLUID OUT>.
- 2. Using a regulator, set the pilot air pressure within the range of 0.1 to 0.5 MPa. Then, the pump operates when power is applied to the solenoid valve Note 2) of the pilot air supply port and fluid flows from the suction port <FLUID IN> to the discharge port <FLUID OUT>. At this time, the throttle on the discharge side is in an open state. The pump performs suction with its own power even without priming. (Dry state suction lifting range: PA3 1 m, PA5 up to 0.5 m Note 3)) To restrict exhaust noise, attach a silencer to the solenoid valve air exhaust port.
- 3. To stop the pump, exhaust the air pressure being supplied to the pump with the solenoid valve of the air supply port.
- Note 1) When used for highly permeable fluids, the solenoid valve may malfunction due to the gas contained in the exhaust. Implement measures to keep the exhaust from going to the solenoid valve side.
- Note 2) For the solenoid valve, use an exhaust center 5 port valve, or a combination of residual exhaust 3 port valve and a pump drive 4 port valve. If air in the drive chamber is not released when the pump is stopped, the diaphragm will be subjected to pressure and its life will be shortened.
- Note 3) When the pump is dry, operate the solenoid valve at a switching cycle of 1 to 7 Hz. If operated outside of this range, the suction lifting height may not reach the prescribed value.
- <Discharge Flow Rate Adjustment>
- 1. The flow rate from the discharge port <FLUID OUT> can be adjusted easily by changing the switching cycle of the solenoid valve on the air supply port.




Dimensions





PA Series




PA3000/5000 Series

Made to Order Specifications

Please contact SMC for detailed dimensions, specifications and lead times.









PA(P)

PAX

A new type of PA5000 with a polypropylene body is now available. Click here for details.

PB

PAF

PA□ PB

● PA3000/5000 Series

1. Products Complying with ATEX

55-PA3110-03-

Products complying with the ATEX Directive

55 Products complying with the ATEX Directive, Category 2
56 Products complying with the ATEX Directive, Category 3

Body size Symbol Body size 3 3/8" 5 1/2"

Wetted body material

Symbol	Body material
1	ADC12 (Aluminum)
2	SCS14 (Stainless steel

Diaphragm material

Cumbal	Diankson motorial	Operating method		
Syllibol	Diaphragm material Automatically operated		Air operated	
1	PTFE	•	•	
2	NBR	•	_	

^{*} Dimensions are the same as those of the standard products.

Actuation

Symbol	Actuation	
0	Automatic operation	
3	Air operated	

Option

C	Option	Operating method	
Symbol	Option	Automatically operated	Air operated
Nil	None	•	•
N	With silencer*	•	ı

- * This product is equipped with a 2504-002 (NPT: 2504-N002)
- * For AIR EXH
- 55-PA: 2504-□002
- 56-PA: AN20-□02
- (
 : Either Nil or N is entered as a thread symbol.)

Port size


C	Port size	Applicable model	
Symbol		PA3000	PA5000
03	3/8"	•	_
04	1/2"	_	•
06	3/4"	-	•

Thread type

• Illicad typ		
Symbol	Type	
Nil	Rc	
N	NPT	
F	G	
T	NPTF	

PA3000/5000 Series

A new type of PA5000 with a polypropylene body is now available. Click here for details.



SMC