Mini Rotary Actuator/Rack & Pinion Style

Series CRJ

Size: 05, 1



CRB2

CRBU2

CRB1

MSU

CRJ

CRA1

CRQ2

MSQ

MSZ


CRQ2X MSQX

MRQ



Mini Rotary Actuator Series CRJ


Rack & Pinion Style/Size: 05, 1



Flexible mounting


A new compact body design not only reduces overall space requirements, but also achieves space-savings in wiring and piping. Ease in mounting is maximized thanks to the merits of the new compact body.

■ Free mounting



■ Wiring and piping direction can be selected depending on mounting conditions.


Mounting examples for auto switch and speed controller






Allowable load improved

Large roller bearing and large diameter output shaft add to overall compactness while ensuring high rigidity. $_{\rm Rolling\ bearing}$




	Model	CRJ05	CRJ1
Allow-	Fr	25	30
able	FS (a)	20	25
(N)	FS (b)	20	25
Outp	ut shaft size (mm)	ø5	ø6



Backlash reduced

Even with a single rack design, the use of a special construction minimizes backlash.



Stopping the pinion gear by having it strike against the flat surface of the piston eliminates backlash. CRB2

CRBU2

CRB1

MSU

CRJ

CRA1

CRQ2

01142

MSQ


MSZ

CRQ2X MSQX


MRQ


■ With external stopper/Series CRJU

4 to 5 times allowable kinetic energy (Basic type compared to CRJB)



Angle is adjustable: ±5° at each rotation end






Series Variations

	Series			Rotatin	g angle		Connection port	+
#	Series		90°	100°	180°	190°	location	Auto switch
	Posio tymo	CRJB05	•	•	•	•		
	Basic type	CRJB 1	•	•	•	•	Front ported	D-F8 type
	With automol storms	CRJU05	•		•	_		D-M9/M9 V type D-M9 W/M9 WV type
	With external stopper	CRJU 1	•	_				- inocumount type

Mini Rotary Actuator Rack & Pinion Style Series CRJ

How to Order




Applicable Auto Switch/Refer to pages 761 to 809 for further information on auto switches.

		F1 .: 1	tor		Loa	ad voltage		Auto swit	ch model	Lead w	vire le	ngth (m)*			
Type	Special function	Electrical entry	Indicator light	Wiring (Output)	DC		AC	Perpendicular entry	In-line entry	0.5 (Nil)	1 (M)	3 (L)	5 (Z)	Pre-wired connector	Applical	ble load
				3-wire (NPN)				M9NV	M9N	•	•	•	0	0		
				3-wire (INPIN)		E\/ 10\/		F8N	_	•	_	•	0	_	IC circuit	
	_			2 wire (DND)	-wire (PNP)	5V,12V		M9PV	M9P	•	•	•	0	0	il Circuit	
등	switch			3-wile (FINE)				F8P	_	•	_	•	0	_		
š				2-wire		12V		M9BV	M9B	•	•	•	0	0		
te 8		Grommet	Yes	_	24V	120		F8B	_	•	_	•	0	_		Relay,
state		Gioinnet	163	3-wire (NPN)	240	5\/ 12\/		M9NWV	M9NW	•	•	•	0	0	IC circuit	PLC
Solid	Diagnosis indication			3-wire (PNP)	1	5V,12V	2V	M9PWV	M9PW	•	•	•	0	0	IC CIICUII	
S	(2-color)			2-wire		12V		M9BWV	M9BW	•	•	•	0	0	_	
				3-wire (NPN)		E\/ 10\/	E\/ 10\/	M9NAV **	M9NA **	0	0	•	0	0	IC circuit	t
	Water-resistant (2-color indicator)			3-wire (PNP)		5V,12V		M9PAV **	M9PA **	0	0	•	0	0	io circuit	
	(2 00.0			2-wire		12V		M9BAV **	M9BA **	0	0	•	0	0	_	

^{**} Although it is possible to mount water-resistant type auto switches, note that the rotary actuator itself is not of water-resistant construction.

1 m M (Example) M9NWM 3 m L (Example) M9NWL 5 m Z (Example) F9NWZ

Refer to pages 796 and 797 for detailed solid state auto switches with pre-wired connectors.




^{*} Auto switches are shipped together, but not assembled.



^{*} Lead wire length symbols: 0.5 m ·······Nil (Example) M9NW * Auto switches marked "O" are produced upon receipt of order.

Specifications



Note) If optimum accuracy of the (rotating) angle is required, select an actuator with external stopper.

Made to Order (Refer to pages 188 and 189 for details.)

Symbol	Specifications/Description
-XA1 to XA17	Shaft Pattern Sequencing I

Allowable Kinetic Energy and Rotation Time Adjustment Range

	Size		Allowable kinetic energy (J)	Rotation time adjustment range for stable operation (s/90°)
0.5	Basic type	CRJB05	0.00025	
05	With external stopper	CRJU05	0.001	0.1 to 0.5
	Basic type	CRJB1	0.0004	0.1 10 0.5
1	With external stopper	CRJU1	0.002	

JIS Symbol



Mass

Туре		Model	Mass (g) Note)
		CRJB05-90	
	05	CRJB05-100	32
	03	CRJB05-180	20
Design trans		CRJB05-190	39
Basic type		CRJB1-90	54
	1	CRJB1-100	54
	CRJB1-180		67
		CRJB1-190	07
	05	CRJU05-90	47
With external	05	CRJU05-180	53
stopper	1	CRJU1-90	70
	1 -	CRJU1-180	81

Note) Values above do not include auto switch mass.





CRB2

CRBU2

CRB1

MSU

CRJ

CD A4

CRA1

CRQ2

MSQ

MSZ


CRQ2X MSQX


MRQ

Series CRJ


Rotating Direction and Rotating Angle


- The shaft turns clockwise when the A port is pressurized, and counterclockwise when the B port is pressurized.
- · For actuators with external stopper, the rotation end can be set within the ranges shown in the drawing by adjusting the stopper bolt.





With external stopper







Note) • The drawings show the rotation range for the shaft's single flat.
• The single flat position in the drawings shows the counterclockwise rotation end when the rotation angle is adjusted to 90° and 180°.


Construction

Basic type: CRJB





With external stopper: CRJU



Component Parts

No.	Description	Material	Note
1	Body	Aluminum alloy	Anodized
2	Piston	Stainless steel	
3	Shaft	Stainless steel	
4	Bearing retainer *	Aluminum alloy	Anodized
(5)	Cover	Aluminum alloy	Anodized
6	Bearing	Bearing steel	
7	Piston seal	NBR	
8	O-ring	NBR	
9	Wear ring	Resin	

No.	Description	Material	Note
10	Magnet	_	
11)	Round head no. 0 Philips screw	Steel wire	Nickel plated
12	Hexagon socket head set screw	Stainless steel	
13	Stopper	Chrome molybdenum steel	Electroless nickel plated
14)	Holder	Aluminum alloy	Anodized
15)	Stopper retainer	Carbon steel	Zinc chromated
16	Hexagon socket head set screw	Steel wire	Nickel plated
17)	Hexagon nut	Steel wire	Nickel plated
(18)	Hexagon socket head cap screw	Stainless steel	

^{*} The mounting position of hexagon socket head set screws (No. 12) varies depending on the connecting port location.

D-□

CRB2

CRBU2

CRB1

MSU

CRJ

CRA1

CRQ2

MSQ

MSZ

CRQ2X MSQX

MRQ




Series CRJ


Dimensions/Size 05, 1

Basic type: CRJB 2 x JC depth JD 窗 2 x J through JA depth of counterbore JB (Opposite side, same location) CB BF CA 16 ВА 2 x M3 x 0.5 depth 4 вв 2 x M3 x 0.5 (Front port) (For side port, use hexagor socket head set screw) \Diamond **(** BC

Note 1) This dimension is for the actuator with D-M9 type auto switch (not including the 2-color indication type).




With external stopper: CRJU



Note 2) For the 180° specification, the slated line area do not exist.

Note 3) The maximum dimensions that appear are those measured at the maximum rotating angle. settings: 100° and 190°.



(mm)


Size	EA	EB	НА
CRJU05	5.6	33.8	6.5
CRJU1	5.6	35.8	7.5

(mm)


Size	Rotating angle	Α	ВА	ВВ	ВС	BD	BE	BF	BG	вн	ВІ	CA	СВ	D	DD	J	JΑ	JB	JC	JD	Н	N	Ø	S	SD	UU	W										
CRJB05	90°	10.5	20	32.4	9.5		6.5	2.5	171	00	7	21.5	5.5	F~C	1060	Mayoz	٠,	0	M4 x 0.7	-	115	10.5	10 5	43	3.4	28	4.5										
CHJDUS	180°	19.5	19.5 30 43	19.5 30	19.5 3	19.5	19.5	19.5	19.5	19.5	19.5	18.5	19.5 30 43	43.4	9.5	11	0.5	3.5	17.1	20	1	27	5.5	byo	10119	IVI4 X U.7	5.6	3.5	W4 X U.7	Э	14.5	12.5	13.5	54	3.4	26	4.5
CD ID 1	90°	00.5	0.5	37.4	10.5	4.4	0	4.5	01.1	00	٥.	24	7.5	00	1.450	M5 0 0	7	4.5	M5 0.0	•	45.5	10.5		48	- 0	00											
CRJB 1	180°	23.5	35	50.4	12.5	14	9	4.5	21.1	22	8.5	30.5	7.5	6g6	14n9	WI5 X U.8	7.5	4.5	M5 x 0.8	ь	15.5	13.5	16.5	61	5.9	32	5.5										




Proper Auto Switch Mounting Position (Detection at rotation end)



For D-M9



For D-F8



	D. J. J.		-M9 auto s	witch	D	-F8 auto sv	witch
Size	Rotating angle	Α	Operating angle θ m	Hysteresis angle	В	Operating angle θ m	Hysteresis angle
05	90°	20.5	400	100	16.5	200	100
05	180°	23.2	40°	10°	19.2	20°	10°
4	90°	22.4	200	4.00	18.4	15°	100
!	180°	25.6	30°	10°	21.6	15	10°

Operating angle θ m: Value of the operating range Lm of a single auto switch converted to an axial rotating angle.

Hysteresis angle : Value of auto switch hysteresis converted to an angle.

Note) The values given in the table above are representative values, not meant to be guaranteed.

In the actual setting, adjust the value after confirming the auto switch performance.

CRB2

CRBU2

CRB1

MSU

CRJ

CRA1

UNAI

CRQ2

MSQ

MSZ

CRQ2X MSQX

MRQ

D-□




Series CRJ (Size: 05, 1) Simple Specials:

-XA1 to -XA17: Shaft Pattern Sequencing I

Shaft pattern sequencing is dealt with a simple made-to-order system. (Refer to front matter 33.) Please contact SMC for a specification sheet when placing an order.

Shaft Pattern Sequencing I



 $[\]ast$ Combination of simple specials and made-to-order, it is possible for up to 2 types shown in chart 1.

Combination Chart of Simple Specials for Tip End Shape

Chart 1. Combination between -XA□ and -XA□

Symbol	Description		port Lower	Applicable size			Comb	ination		
XA 1	Female thread at the end	•	_		XA1					
XA 2	Female thread at the end	_	•		•	XA2				
XA13	Shaft through-hole	•	•		_	_	XA13			
XA14	Shaft through-hole and female thread at the end	•	_	05, 1	_	_	_	XA14		
XA15	Shaft through-hole and female thread at the end	_	•		_	_	_	_	XA15	
XA16	Shaft through-hole and double shaft-end female thread	•	•		_	_	_	_	_	XA16
XA17	Shortened shaft	•	_			•	•	_	•	_



Series CRJ (Size: 05, 1) **Simple Specials:**

-XA1 to -XA17: Shaft Pattern Sequencing I

Shaft pattern sequencing is dealt with a simple made-to-order system. (Refer to front matter 33.) Please contact SMC for a specification sheet when placing an order.

Shaft Pattern Sequencing I

-XA1 to -XA17

Additional Reminders

(mm) Q1

МЗ

М3

M3,M4

M3,M4

- 1. Enter the dimensions within a range that allows for additional machining.
- 2. SMC will make appropriate arrangements if no dimensional, tolerance, or finish instructions are given in the diagram.
- 3. The length of the unthreaded portion is 2 to 3 pitches.

• The maximum dimension L1 is, as a rule, twice the thread size

Q1 = M []]

4. Unless specified otherwise, the thread pitch is based on coarse metric threads. M3 x 0.5, M4 x 0.7

The long shaft can be further shortened by machining female threads into it. (If shortening the shaft is not required, indicate "*" for dimension X.)

- 5. Enter the desired figures in the [___] portion of the diagram.
- 6. Chamfer face of the parts machining additionally is C0.5.
- 7. The additionally machined port will have an aluminum surface since it is left unfinished.

CRB2

CRBU2

CRB1

MSU

CRJ

CRA1

MSQ

MSZ

CRO2X

CR02

MSQX

MRQ

1.5 to 14.5

8 to 14.5

1.5 to 15.5

8 to 15.5

Size

CRJB05


CRJU05

CRJB 1

CRJU 1

A special end is machined onto the short shaft, and a through-hole is drilled into it. Female threads are machined into the through-hole, whose diameter is equivalent to

• The maximum dimension L2 is, as a rule, twice the thread size. (Example) For M4: L2 = 8




		(mm
Size Thread	05	1
M3 x 0.5	ø2.5	ø2.5
M4 x 0.7		ø3.3

A2

(Example) For M3: L1 = 6

Machine female threads into the short shaft

 The maximum dimension L2 is, as a rule, twice the thread size. (Example) For M4: L2 = 8



	(mm)
Size	Q2
05	М3
1	M3, M4

A special end is machined onto both the long and short shafts, and a through-hole is drilled into both shafts.


Female threads are machined into the through-holes, whose diameter is equivalent

• The maximum dimension L1 is, as a rule, twice the thread size.

• The maximum dimension L1 is, as a rule, twice the thread size.

(Example) For M3: L1 = 6

• Equal dimensions are indicated by the same marker.




		(mm)
Size Thread	05	1
M3 x 0.5	ø2.5	ø2.5
M4 x 0.7	_	ø3.3

A13

Shaft with through-hole


Minimum machining diameter for ød1 is 0.1.



	(mm)
Size	d1
05	ø2 to ø2.5
1	ø2 to ø3.5

A17


Shorten the long shaft.



(mm)
Х
1.5 to 14.5
8 to 14.5
1.5 to 15.5
8 to 15.5

A special end is machined onto the long shaft, and a through-hole is drilled into it. Female threads are machined into the through-hole, whose diameter is equivalent to the pilot hole diameter.

 The maximum dimension L1 is, as a rule, twice the thread size. (Example) For M3: L1 = 6



		(mm)
Size Thread	05	1
M3 x 0.5	ø2.5	ø2.5
M4 x 0.7	_	ø3.3

D-□



Series CRJ Specific Product Precautions

Be sure to read before handling.

Refer to front matters 38 and 39 for Safety Instructions and pages 4 to 13 for Rotary Actuator and Auto Switch Precautions.

Rotation Adjustment

⚠ Caution

As a standard feature, the actuator with external stopper is equipped with a rotation angle adjustment screw that can be used to adjust the angle of rotation.

Size	Angle adjustment per single rotation of angle adjustment screw
05	2.3°
1	2.3°

The rotation adjustment range for the actuator with external stopper is $\pm 5^{\circ}$ at each rotation end. Please note that adjusting beyond this range, may cause product malfunction.

Mounting of Speed Controller and Fittings

⚠ Caution

The M3 \times 0.5 piping port is used. In case the speed controller or fittings are directly connected, use the series listed below.

- Speed controller AS12□1F/Elbow type AS13□1F/Universal type
- One-touch fitting One-touch mini Series KJ
- Reducer bushing Series M3


Mounting of Auto Switch

⚠ Caution

If a size 05 actuator with auto switch is being used, keep the magnetic body away at least 2 mm or more from the bottom of the actuator.

If the magnetic body comes closer than 2 mm, malfunction of the auto switch may occur due to the magnetic force drop.

* When using the bottom face for mounting, a non-magnetic spacer (such as aluminum) is required as shown below.



Maintenance


∧ Caution

This product requires special tools; therefore, it cannot be disassembled for maintenance.

External Stopper Unit

∧ Caution

Order external stopper unit with the unit part numbers shown below.




Model	Unit part no.
CRJU05-90	P531010-1
CRJU05-180	P531010-2
CRJU1-90	P531020-1
CRJU1-180	P531020-2

Note 1) External stopper units for 180° cannot be applied to the 90° Mini-rotary Actuators.

Note 2) When using external stoppers for 90°, use Minirotary Actuators with a rotation range of 100°, and for 180°, use actuators with a rotation range of 190°.

External Stopper Assembly Procedure

* Actuators with external stopper (Model CRJU) come already assembled; therefore, the following procedure is not required.



1. Assemble the stopper retainer to the stopper temporarily.

Then place the stopper retainer in the single flat position and tighten with hexagon socket head cap screws. Leave a space of approximately 0.5 mm between the stopper and the Minirotary actuator, as shown in Fig. (1).

Tighten the hexagon socket head cap screws evenly so that the stopper retainer is not unevenly tightened as in Fig. (2). Furthermore, take precautions to avoid applying excessive force to the shaft when tightening.

2. Tighten the holder assembly with hexagon socket head cap screws.

	Tightening torque (N·m)
Hexagon socket head cap screw	0.8 to 1.2

